

**REX**


50/60Hz

PIPE THREADING MACHINE


# FP80A Series

## OPERATION MANUAL

Original Instruction



CE UK  
CA



Be sure to read this Operation Manual before using the machine.

- Note -

- Be sure to hand this Operation Manual to the user.
- To ensure safe and efficient use, read the manual thoroughly before using the machine.
- Be sure to keep the Operation Manual where the operator can refer to it whenever necessary.

Date of purchase:                      Year                      Month

Distributor / Dealer:

Thank you for purchasing a REX Pipe threading machine.

Precision-engineered for cutting, reaming, threading and, with our optional Portable Groovers, grooving steel and stainless steel (option) pipes, our product will give you years of reliable service if you simply follow the instructions in this Operation Manual carefully.

Before using the machine, make sure you read the Operation Manual from start to finish, paying particular attention to the Safety Considerations on pages 1 & 2 and Precautions on pages 3 & 4. To avoid accident and injury, never use the machine for any purposes other than those described in this Operation Manual.

Should you need further advice, contact your distributor, dealer or REX INDUSTRIES CO., LTD.

---

## CONTENTS

---

Safety Considerations .....	1
Precautions .....	3
Main Parts, Specifications, Standard Accessories, Usage.....	5
Getting Ready	
1. Transportation .....	6
2. Setting up .....	6
3. Cutting oil .....	6
4. Attaching the Die-head .....	6
5. Removing or replacing the Dies .....	7
6. Setting up the pipe / Removing the pipe .....	10
7. Power supply .....	10
8. Checks before starting / CE compliant switch .....	11
9. Cutting pipes / Precautions when threading .....	12
10. Reaming / Points to watch when threading .....	13
Operation Guide	
11. Cutting threads (Manual-open Die-head) .....	14
12. Cutting threads (NV-auto Die-head) .....	14
13. Cutting threads (Uni-auto V Die-head) .....	16
14. Cutting threads (Self-opening Die-head) .....	17
15. Adjusting the oil flow .....	19
16. Measuring threads with a gauge .....	19
Optional Accessories .....	21
Maintenance and Care	
1. Grease, Oil .....	22
2. Replacing the Carbon brushes .....	22
3. Cleaning the Tank .....	23
4. Structure and care of the Chuck jaw set .....	23
5. Wiring diagram .....	23
Servicing and Repairs .....	24
Troubleshooting .....	24
Explanation of Symbols .....	25

---

Definitions of **⚠ WARNING** and **⚠ CAUTION**

In this Operation Manual, warnings are divided into **⚠ WARNING** and **⚠ CAUTION**.

**⚠ WARNING** : indicates actions which could possibly result in death or severe injury to the user if the machine is used incorrectly.

**⚠ CAUTION** : indicates actions which could possibly result in injury to the user, or physical damage, if the machine is used incorrectly.

Even items labelled **⚠ CAUTION** could have serious results under certain conditions.

Be sure to observe these warnings carefully as they greatly affect safety.

- If this Operation Manual is lost or damaged, promptly order a replacement from your distributor, dealer or link to <http://www.rexind.co.jp/e/>

- Parts and specifications are subject to change without prior notice, due to improvements in quality, performance or safety standards. In such cases, the contents, photographs, illustrations, etc. in the Operation Manual may be different to the product you have purchased.

---

## ▲ WARNING

### 1. Ensure you use the correct voltage.

- Be sure to use the voltage indicated on the name plate of the main unit or in the Operation Manual. If the voltage is different from the voltage indicated, overheating, smoke or fire may occur.

### 2. Check the switch is OFF before inserting the plug into the power supply socket.

- If the plug is inserted into the power supply when the switch is ON, the machine may start operating abruptly and is liable to cause accidents. Be sure to check the switch is OFF.

### 3. Be sure to avoid electric shock.

- Do not touch the plug with wet hands.
- Do not use the machine in rain or in places where moisture can easily get into the machine.
- Be sure to ground the machine to avoid electric shock.

### 4. Using Flammable Sprays.

- Flammable sprays (e.g. aerosols used to clean parts) must be used at a safe distance from the machine.
- When cleaning cut threads with an aerosol parts cleaner, ensure that you do so away from the machine as there is a risk of ignition or explosion from sparks generated when switching ON or OFF.

### 5. Take notice of conditions at the work site.

- Do not use the machine in rain, humid or damp places, or places where moisture can easily get into the machine. Humidity will lower insulation of the motor and cause electric shock.
- Do not use close to flammable fluids or gases, such as gasoline and thinner. Fire or explosion might occur.

### 6. Use designated accessories and attachments.

- Do not use accessories and attachments other than those designated in the Operation Manual or our catalogues. Accidents or injuries might result.

### 7. In the following cases, turn the main unit OFF and pull the plug out of the power supply socket.

- When the machine is not in use or parts are changed, repaired, cleaned or inspected.
  - When accessories are changed.
  - When hazards are expected (including electric power failure).
- If the machine is plugged in, it may start operating unexpectedly, causing accidents.

### 8. If any abnormality is noticed, stop operation immediately.

- If the machine does not operate smoothly, or abnormalities such as unusual odours, vibration or noise are detected, stop operating the machine immediately.
- Check symptoms against the items in the section entitled, "Troubleshooting" at the end of the Operation Manual and observe the corresponding instructions. If the machine is used continuously, overheating, smoke or fire might occur, causing accident or injury.
- If overheating or smoke from the unit occurs, do not attempt an overhaul yourself but ask for an inspection and repair.

### 9. Keep the work site clean.

- Ensure you keep the work table and the work site in good order and well lit.
- A cluttered site and work table are liable to cause accidents.

### 10. Do not let unauthorised personnel near the machine.

- Do not let anyone other than authorised personnel touch the main unit or the power cord, or operate the machine.
- Do not let anyone other than authorised personnel enter the work site, especially children. Injuries might occur.

### 11. Do not use the machine with excessive force.

- To ensure safe and efficient operation, use within the capacity of the main unit. Applying force may not only cause damage to the product but could also result in accident or injury.
- Do not use the machine in any way that could cause the motor to lock, or cause smoke or fire.

# Safety Considerations

## ▲ WARNING

### **12. Use the machine only for its designated purpose.**

- Do not use the machine on pipes not specified in the Operation Manual. Using the machine for any purpose other than threading pipes, such as fastening the pipe to a joint etc., will not only damage the machine and/or motor but could also lead to accident or injury.

### **13. Wear appropriate clothing.**

- Do not wear neckties, clothes with unbuttoned sleeves, loose clothing, accessories such as necklaces, etc. Do up buttons and zippers which could get caught in the rotating parts and result in serious accident or injury.
- When working outdoors, it is recommended that you wear rubber gloves and non-slip shoes. Slippery gloves and shoes are liable to cause injuries.
- Do not wear scarves and cover long hair with caps or hair nets to prevent them getting caught in rotating parts.
- Wear safety caps, safety shoes, etc. according to the working environment.

### **14. Do not work in an unnatural posture.**

- Keep a firm footing and balance to avoid falling over and injuring yourself.

### **15. Remove tools such as wrenches.**

- Before turning the switch ON, check that tools used for inspection and adjustment have been removed. If you use the machine when tools are left inside it, accidents and injuries may occur.

### **16. Operate the unit with great care.**

- Always work with great attention to how you handle and operate the machine and to the surrounding conditions. Carelessness may result in accident or injury.
- Do not operate the machine when concentration is lowered such as when tired, after drinking alcohol, when sick, affected by medicines, etc.

### **17. Do not handle the power cord carelessly.**

- Do not carry the product by the cord, or pull the plug out of the socket with the cord.
- Do not place the cord near heated objects, fats & oils, cutters and objects with sharp edges.
- Take care not to tread on the cord, pull the cord or apply unnecessary force resulting in damage to the cord. Electric shock or short-circuit may occur, causing fire.

### **18. Perform careful maintenance daily.**

- When changing accessories and parts, follow the Operation Manual. Periodically inspect the Power supply cord and plug. If damaged, ask your distributor or dealer for repairs.
- If an extension cord is used, inspect the cord periodically and, if damaged, replace it.
- If extension cords are used outdoors, use extension cords designed for outdoor use to prevent electric shock, short-circuit or fire.
- Keep parts used for gripping dry and clean, and free of oil and grease. If your hands slip, you may be injured.

### **19. Check for damaged parts.**

- Before using the machine, carefully check for damage to the protective cover and other parts, and check both normal operation and specified functions.
- Check for any abnormalities such as in adjustment of movable parts, tightening, damage to and installation of parts and all parts affecting operation.
- Do not use machines with a damaged power cord or plug. Doing so may cause electric shock or a short circuit leading to fire.
- Do not use machines if the stop and start switches do not work properly. In replacing or repairing a broken protective cover and other parts, follow the Operation Manual. If no instructions are specified in the Operation Manual, ask your distributor or dealer for repairs.

### **20. Store carefully when the machine is not in use.**

- Store in a dry place away from children and locked with a key.

### **21. For overhaul and repair of the machine, ask an appointed REX agent.**

- Our products comply with corresponding safety standards. Do not remodel.
- Be sure to ask your distributor or dealer for any repairs. If repairs are carried out by unskilled or unqualified personnel, the performance of the unit will be adversely affected and may result in accident or injury.

## Threading

### ▲ WARNING

#### 1. Take care when handling the blades.

- To prevent accidents and injuries, take special care when handling blades such as Dies, Reamer, Pipe cutter and Carbide cutter.

#### 2. Do not put your hands or face near rotating parts when the machine is in use.

- You could get caught in rotating parts or hit by scrap, resulting in accident or injury.

#### 3. Do not perform the next job until rotation stops completely.

- When you turn the switch off, rotation does not stop immediately. Perform the next job only after checking that the machine has come to a complete stop. Failure to do so may result in accident or injury.

#### 4. Do not wear gloves when operating the machine.

- Gloves may get caught in rotating parts or blades, resulting in accident or injury.

#### 5. Do not leave the machine while it is still rotating.

- Others may be injured.

#### 6. If you accidentally drop or hit the machine, carefully check for damage, cracks, deformities or any abnormalities.

- If abnormalities are found, ask your distributor or dealer for an inspection and/or repair.
- Continuing to use the machine when damaged will likely lead to mechanical problems, accident or injury.

#### 7. Do not touch the Dies or scrap just after threading.

- The Dies and scrap can become very hot just after threading; touching them could burn or injure you.

#### 8. Die-head and Dies.

- Use the Die-head and Dies that are appropriate for the type and diameter of pipe to be processed.
- When threading stainless steel pipes use pipes with a wall thickness equivalent to Schedule 40 or more.
- Make sure the Die-head is mounted correctly on the Carriage. Be careful not to get your fingers caught.
- Before you start threading, set the Die-head in the threading position, switch ON, and check that the oil is flowing correctly over the Dies. Failing to do so could result in an imperfect thread, damage to the machine, accident or injury.

#### 9. Be sure to check the starting position before threading.

- When threading, start with the Carriage to the right of the red line on the Carriage support bar A (as viewed from the working position).
- If the Carriage is not in the correct starting position, the Die-head will bang into the main unit while threading, causing mechanical problems, accident or injury.

#### 10. Use a pipe support when threading long pipes.

- When threading long pipes, use a pipe support to prevent both vibration due to warping while the pipe is rotating and instability of the machine due to the weight of the workpiece.
- If a pipe support is not used, threading cannot be performed correctly and problems with the machine, accident or injury may occur.

#### 11. Be sure to attach accessories according to the Operation Manual.

- Attaching accessories incorrectly may cause the machine to topple over resulting in accident or injury.

## Reaming

### ▲ WARNING

The Reamer blade is very sharp; to prevent injury, avoid touching it with bare hands.

# Precautions

## Cutting

- Using the Pipe cutter

### ⚠ CAUTION

When cutting pipes, turn the Cutter handle no faster than  $\frac{1}{2}$  rotation per rotation of the pipe.  
- If the Cutter handle is turned too quickly when engaging the pipe, it can distort the shape of the pipe and may not make a proper thread.

## Handling pipe threading oil

### ⚠ WARNING

1. Wear goggles.
  - Touching the eyes with oil may cause inflammation.
  - Emergency treatment : Wash eyes with clean water for about 15 minutes and seek medical attention.
2. Wear protective gloves.
  - If oil comes into contact with the skin, it may cause inflammation.
  - Emergency treatment : Carefully wash the affected part with soap and water.
3. Take care not to breathe in oil mist or steam.
  - Breathing in oil mist or steam may cause nausea.
  - Emergency treatment : Carry the person out into the fresh air, cover them with a blanket, keep them warm and relaxed, and seek medical attention.
4. Do not thin the oil or mix it with threading oil produced by other companies.
5. If water gets mixed in with the threading oil and the colour changes to milky white or the oil deteriorates excessively resulting in a poor finish, change to fresh oil promptly.
6. Do not drink the oil.
  - Drinking the oil may cause diarrhoea or vomiting.
  - Emergency treatment : Seek medical attention immediately, without forcing the person to vomit.
7. Do not place the oil where it is easily reached by small children.
8. Be especially careful of fire.
9. Storage.
  - Always close the lid after use to prevent the oil from being contaminated by dust, water or other foreign bodies.
  - Store in a dark place away from direct sunlight.

## When using threading oil for water mains pipes and water-immiscible cutting fluid for threading

### ⚠ CAUTION

Handling waste oil and waste cans.

- Handle materials according to local laws and regulations regarding waste disposal and cleaning.
- If uncertain, consult your distributor or dealer.

## When using threading oil for stainless steel pipes

### ⚠ WARNING

1. Do not burn off the oil.
  - Oil contains chlorine compounds and generates toxic gas when burnt.
  - In the case of an emergency in which someone has inhaled such toxic gases, carry the affected person out into the fresh air and seek medical attention.
2. Disposal of waste oil and cans.
  - Follow all laws and regulations related to the disposal and cleaning of waste materials.
  - When uncertain, consult your distributor or dealer.

# Main Parts, Specifications, Standard Accessories, Usage

## Main parts




Fig. 1

## Specifications

Model	FP80A Series
Threading capacity	½" (15 A) - 3" (80 A)
Type of thread	Standard Taper Pipe Thread
Power supply	110 - 120 V(50/60 Hz), 220 - 230 V(50/60 Hz)
Rated Motor Power	Input 1600 W / Output 1000 W
Motor Type	Universal Motor, Single Phase
Rotation speed	31 r.p.m. (unloaded)
Net weight	69 kg
Dimensions	770 mm (L) X 480 mm(W) X 405 mm(H)
Chuck type	K-type chuck, S-type chuck jaw insert

Table 1

## Standard Accessories

	FP80A	FP80AV	FP80AV/III-CE
Die-head	Manual (½ - 2")	Self-opening or NV-auto (½ - 2")	Self-opening or NV-auto (½ - 2")
	Manual (2½ - 3")	Manual (2½ - 3")	Self-opening (2½ - 3")
Dies	(½ - ¾") (1 - 2") (2½ - 3")		One set each
Cutting oil	Miyagawa 50W-R		1 can (4 L)
Pipe stands / leg caps			4 / 4 *Model without pipe stand and leg cap also available
Hexagonal keys	3, 4, 5, 6 mm		4

Table 2

**Usage:** The machine is designed for cutting, reaming and threading steel and stainless steel pipes only. Do not use for any other purpose whatsoever.

# Getting Ready (Transportation / Setting up / Cutting oil / Attaching the Die-head)

## 1. Transportation

When moving or transporting the machine, remove the Oil pan. There is no need to drain off the Cutting oil in the Tank. (Fig. 2)

### - Manual open Die-head

Chuck a piece of pipe securely, loosen the Lever nut on the Die-head and open the Dies. (So that the Dies do not drop out, place the Eccentric handle in the thread cutting position.)

Lower the Pipe cutter, fix the pipe with the Cutter rollers and Cutter wheel, and then move the machine.

### - NV-auto Die-head, Uni-auto V Die-head, Self-opening Die-head

Before moving the machine, chuck a piece of pipe securely and fix the pipe with the Cutter.




Fig. 2

## 2. Setting up

Place the machine on a flat surface.

Even when placed on a flat surface, the Rear chuck of the machine is designed to be in a slightly raised position. (Fig. 3)

### ⚠ WARNING

If the Rear chuck is too low, oil will flow out of the pipe, making the floor dirty and wasting oil.

### - Mounting on Pipe stands

Using third-party Stand base may result in the machine falling over. Ensure you use only genuine REX Stand base.

Insert the Pipe stands into the sockets located in each corner of the bottom of Stand base, and fix in position with the four Wing screws provided. (Fig. 4)

Once the machine is set up, be sure to place the Oil pan in its correct position.




Fig. 3

## 3. Cutting oil

Fill the Tank with the Cutting oil that is supplied with the machine. Use only genuine REX Cutting oil.

- For stainless steel pipe only "Miyagawa 100SW-RN" (Black can)
- Water washable "Miyagawa 50W-R" (Blue can)
- Standard "Miyagawa 246-R" (Red can)

### ⚠ WARNING

Miyagawa 100SW-RN Cutting oil for stainless steel pipe can only be used for threading stainless steel pipe. Using this oil for threading pipes made of other materials may result in irregular threads.




Fig. 4

## 4. Attaching the Die-head

Attach the Die-head that matches the size of pipe to be threaded to the machine.

-Attach the Die-head to the machine.

-Align the Die-head post to the Carriage fitting hole, and push it until it contacts the Carriage while moving the Die-head up and down a little. (Fig. 5-1)

-Lower the Die-head and check it is positioned correctly. (Fig. 5-2)

\*Note: Remove the Die-head by following the above in the reverse order.




Fig. 5

## 5. Removing or replacing the Dies


Make sure you insert the dies into the Die-head in the correct way.

### Manual-open Die-head

(There is no need to remove the Die-head from the machine.)

#### Removing the Dies

- Knock the Eccentric handle to the right, loosen the Lever nut and push the Eccentric handle over to the far left. (Fig. 6)
- In this position, Dies No. 3 and No. 4 can then be removed.
- Raise the Die-head and you can remove Dies No. 1 and No. 2.




#### Replacing the Dies

- Ensure the number on the Dies corresponds with the number of the slot on the Die-head.
- Insert each Die until the notch is engaged. (Fig. 7)
- Pull the Eccentric handle back in the opposite direction, left of the arrow; (Fig. 6) The Dies will move towards the centre of Die-head.

\*Note: If the Eccentric handle does not move into position properly, move the Dies up and down a little while pushing and pulling the Eccentric handle gently and try again.

\*Note: Dies are made as a matched set of four, so be sure to use them as such and replace them all at the same time. Do not attempt to replace just one or two of the set, as cutting will be adversely affected.




### NV-auto Die-head

(There is no need to remove the Die-head from the machine.)

#### Removing the Dies

- Open the Die-head. (Fig. 8)
- (i.e. Pull the Auto-open lever B as shown by the arrow marked "Open")
- Loosen the Lever nut (Fig. 8), pull the Cam plate as far as it will go in the direction of the arrow, and lightly tighten the Lever nut. Dies No. 3 and No. 4 can be then removed. (Fig. 9)
- Raise the Die-head and you can remove Dies No. 1 and No. 2.




#### Replacing the Dies

- Match the number on the Die to the corresponding number on the Die-head.
- Insert the Die until the notch clicks into position.
- Push the Cam plate back; the Dies will move towards the centre of the Die-head.

\*Note: If the Dies do not move into position properly, move them up and down a little and try again.

\*Note: Dies are made as a matched set of four, so be sure to use them as such and replace them all at the same time. Do not attempt to replace just one or two of the set, as cutting will be adversely affected.



# Getting Ready (Removing or replacing the Dies)


## 5. Removing or replacing the Dies

### Uni auto V Die-head

(There is no need to remove the Die-head from the machine.)

#### Removing the Dies


- Push the Auto-open lever A in the direction of the arrow (Fig. 10-1) and put the Die-head into the open position.
- Loosen the Lever nut by turning in the direction of the arrow (Fig. 10-2) and fully pull the Cam plate in the direction of the dies-open position. (Fig. 10-3)




Remove the Dies from the Die-head. (Fig. 11)

#### Replacing the Dies


Insert each die into its corresponding slot number on the Die-head as far as the line marked on each die. (Fig. 12)



Push the Cam plate in the direction of the arrow (Fig. 13-1) and tighten the Lever nut on the appropriate pipe size position. (Fig. 13-2)



Next push the Cam plate upwards in the direction of the arrow and set in position. (Fig. 14)



## Self-opening Die-head

(There is no need to remove the Die-head from the machine.)

### Removing the Dies (Fig. 15)

- After opening the Die-head (i.e. with the Open lever removed from the groove on the block and the Dies in the open position) remove the Size setting lever from the Size setting pin.
- Turn the Cam plate handle in the direction of the arrow. Dies No.3 and No.4 can then be removed.
- Raise the Die-head and remove Dies No.1 and No.2.




Fig. 15

### Replacing the Dies (Figs. 16-1, 2)

- Raise the Die-head and insert the replacement No.1 and No.2 Dies until the Notch is engaged. Ensure that the number on the Dies corresponds to the number on the Die-head; if Dies are inserted incorrectly, cutting will be impaired.
- Lower the Die-head and replace Dies No.3 and No.4 in the same way.
- Turn the Cam plate handle back in the direction of the arrow. The Dies will then automatically fall into place for cutting. If the Dies do not move into position properly, move them up and down a little and try again.




Fig. 16-1

Fig. 16-2

### ⚠ CAUTION

Dies are made as a matched set of four, so be sure to use them as such and replace them all at the same time. Do not attempt to replace just one or two of the set as cutting will be adversely affected.

### 3" Double Cutting Mechanism (Figs. 17, 18)

The 3" Self - opening Die-head employs a double cutting mechanism. Basically, the Die-head functions in much the same way as other Die-heads, but if the voltage is low or something similar occurs, and a clean thread cannot be achieved in one go, then follow the instructions below and cut the thread a second time.

- Place the Die-head in its ready position.
- Lower the Size setting lever and, with the Double cut adjustment plate in contact with the Size setting lever pin, cut the first thread.
- Once the first thread is cut, lift up the Size setting lever, and insert the Size setting lever pin into the groove on the Lever.
- Place the Die-head in the ready position again, and cut a second time to create a standard thread.




Fig. 17




Fig. 18


# Getting Ready (Setting up, Removing the pipe / Power supply)

## 6. Setting up the pipe / Removing the pipe

### ⚠ WARNING

- Do not install or remove a pipe when the machine is moving, such as when operating the machine or just after you switch it off. If you do, you may get entangled, leading to accident or injury. Start operation after you make sure the machine has come to a complete standstill.
- When installing or removing the pipe, remove the plug from the power outlet or the machine could suddenly start operating leading to injury or accident.


- Open the Hammer chuck and Rear chuck scroll wider than the size of the pipe to be threaded.
- Insert the pipe from the Hammer chuck side with a length that cannot be reached to the Rear chuck, but longer pipes from Rear chuck scroll side. (Fig. 19)
- Tighten the Rear chuck scroll to engage the pipe, and ensure it is properly centred in the inserts.
- Tighten the Hammer chuck by Hand wheel to clamp the pipe, and ensure it is centred in the inserts.
- Pull the Hand wheel sharply towards you to lock.
- A sharp jerk in the opposite direction will release the pipe once you have finished threading.
- Next, remove the pipe after releasing the Rear chuck scroll.



### Suggestions for short pipes

- Lightly grip the pipe with the Chuck, gently engage the Dies with the end of the pipe to be threaded, and then tighten the Hammer chuck again. (Fig. 20)

\*Note: Chuck the pipe with the pipe protruding at least 90 mm from the edge of the Chuck jaw insert. (Fig. 20)




### Suggestions for long pipes

- When threading long pipes, use a pipe support to avoid excessive vibration etc. while the pipe is rotating, and to prevent the machine from becoming unstable under the weight of the workpiece. (Fig. 21)

#### Use the REX Pipe support

Model: Hi-Support Code No.170051  
Keeps long pipes stable.



### ⚠ WARNING



Not using a pipe support may result in irregular threads, damage to the machine and/or accident or injury.

## 7. Power supply

Before using the unit, check the voltage on the Name plate. Use only an AC power supply. If an Extension cord is used, it must be as short as possible and of sufficient capacity for the power supplied (at least 2 mm<sup>2</sup> Cabtyre cable rated for outdoor use, 20 A for 110- 120 V and 10 A for 220-230 V). (Fig. 23)

### ⚠ WARNING

- Before connecting the plug to the socket, check that the machine switch is turned OFF to prevent abrupt movements that could lead to accident or injury.
- When you use a 110 - 120 V power supply, ensure it is earthed or you may get an electric shock. If the power socket is already earthed, first remove the supplied adapter with the earth.



## 8. Checks before starting

### ⚠ WARNING

Carry out the following checks before starting to cut or thread pipes. Should any problems arise, refer to "Troubleshooting" at the end of this Operation Manual and follow the appropriate instructions.

Continuing to use the machine when a problem has arisen can lead to accident or injury.

Turn on the machine to set the Main shaft in motion. (Fig. 24)


- Check there are no abnormal sounds or odours coming from the motor.
- Check the pipe you installed does not vibrate abnormally.  
If it does, install it again.
- Check that Cutting oil flows as it should from the Die-head.  
Confirm that there is at least 4 liters of Cutting oil in the tank.

Allow the machine to rotate without any load for several minutes.

- Check the motor does not become abnormally hot, etc.

Turn the machine off and allow it to stop rotating.

- Ensure that the motor stops rotating.




### CE compliant switch

#### Using the Foot switch

To comply with EU regulations the unit incorporates a foot switch. The foot switch has a mechanism by which pressing down on the pedal turns the current on and releasing the pedal turns it off and stops the machine. (Fig. 25)

### ⚠ WARNING

- Place the foot switch in a position where it is easy to use, close to where you are working.
- Be sure to switch Off if there is a sudden power cut. If you leave the machine on, then once the power comes back on the machine will suddenly start up, which could lead to accident or injury.




#### Using the Cam switch

If the Cam switch is placed in the FWD position, the Hammer chuck will rotate in an anticlockwise direction (normal rotation) as seen from the Chuck. In the REV position, it rotates in a clockwise direction (reverse rotation). (Fig. 26)

### ⚠ WARNING

- Do not attempt to cut, ream or thread steel or stainless pipes in the REV position.
- When switching from FWD (normal rotation) to REV (reverse rotation) or, conversely, from REV to FWD, be sure to turn OFF first before operating the machine again.
- The machine will not start rotating unless both the Foot switch and Cam switch have been turned ON.
- Be sure to turn the Cam switch OFF whenever you leave the machine.



The Off position is normally used only to turn the machine off at the end of a work session.

# Getting Ready (Cutting pipes)


## 9. Cutting pipes

- Raise the Die-head and Reamer.
- Position the pipe so that it is ready for cutting and fasten the pipe securely with the Hammer chuck.
- Open the Pipe cutter wider than the diameter of the pipe, lower it into position and turn the Cutter handle, bringing the Cutter close to the position where the Cutter wheel and the Cutter rollers lightly press against the pipe.
- Switch the machine on (Fig. 24) or turn the Cam switch to the FWD position. (Fig. 26)
- Turn the Cutter handle up to ½ a turn for each rotation of the pipe. (Fig. 27)

\*Note: If the Cutter handle is turned too quickly, it will affect the shape and finish of the thread.

### ⚠ CAUTION

Be sure to position the Cutter correctly before the pipe starts rotating.  
If it is not in the correct position it could damage the pipe or the machine.



## Special precautions when you cut a pipe with another cutter

We strongly recommend that only the Cutter attached to the machine be used to cut pipes.


If another cutter is used, ensure that the pipe end is at right angles to the axis of the pipe. (Fig. 28-A)

If the pipe is not square on, as in Fig. 28-B and C, threads may be defective. B and C may be the result of the following:

- (Fig. 28-B)
- The bearing or chucking of the Cutter is unstable.
- When a grinder is used with excessive force (especially in the case of large diameter pipes.)
- When the pipe is engaged at an angle when cutting. (Fig. 28-C)
- When you have cut a large diameter pipe 2 or 3 times with a small grinder.

### ⚠ CAUTION

If the end of the pipe is slanted (Fig. 28-B) or has steps in it (Fig. 28-C), it is not only impossible to make a perfect thread, but may even result in damage to the machine, accident or injury.




## Precautions when threading

Care when the Dies come into contact with the pipe (Fig. 29) Engage the cutting edge of the Dies very lightly with the end of the pipe.

Bringing the Dies too forcefully into contact with the pipe will result in damage to the Dies and shorten their working life.

Once the Dies engage the end of the pipe, apply light pressure to the Carriage handle in a clockwise direction and then gradually increase the pressure.

As the Dies cut into the pipe, it is no longer necessary to apply pressure to the Carriage handle as the Carriage will move on its own.



## 10. Reaming

- After cutting the pipe with the Cutter, be sure to use the Reamer to chamfer the inside of the pipe before making a thread. (Figs. 30, 31)

- Lift the Die-head and Cutter out of the way.

### Reamer with a shaft

- Lower the Reamer arm and set it in position on the Carriage, then push the Reamer shaft toward the pipe. (Fig. 30-1)

\* Note: Reaming is possible without pushing the shaft when a pipe is chucked long enough from the Chuck.

- Lock the Reamer in position by turning the Reamer shaft anti-clockwise. (Fig. 30-2)

- Turn the machine on to start the pipe rotating. Then turn the Carriage handle to the right to move the Reamer forward to engage the pipe.

Allow the pipe to rotate at least ½ a turn, then remove the Reamer from the pipe.

That completes the reaming process. (Fig. 31)




Fig. 30




Fig. 31

## ▲ CAUTION

- Do not use excessive force when pressing the Reamer against the pipe as this may scratch the pipe or even damage the machine.
- The Reamer blade is extremely sharp. NEVER touch it with your bare hands, as you could be seriously injured.

## Points to watch when threading

The FP80A Series comes with the Manual, NV-auto, Uni-auto Die-head (½ - 2"), Self-opening Die-head (2 ½ - 3") and 3 sets of Dies (½ - ¾"), (1 - 2"), (2½ - 3") as standard accessories.

Check that the Die-head and Dies you are using are suitable for the pipe you are working on.

### Manual-open Die-head

- Before adjusting the size of the thread to be cut, bring the Eccentric handle towards you, until it is in the position indicated. (Fig. 32-1)

- Tighten the Lever nut securely by hand.

- Thread size can be simply adjusted with the Lever nut. Move it towards you to increase, and away to decrease the thread size. (Fig. 32-2)




Fig. 32-1

Fig. 32-2

### NV-auto, Uni-auto Die-head

#### For NV-auto Die-head

- When setting the size of the thread to be cut, first push down the Open lever A until it is in the set position and then match the mark on the Cam plate fixing pin with the mark on the Size plate according to the pipe size scale on the Die-head. (Fig. 33-1)

#### For Uni-auto Die-head

- Loosen the lever nut and set the index line to the desired thread size. (Fig. 33-2)

#### For NV-auto Die-head & Uni-auto Die-head

- Tighten the Lever nut securely by hand. (Figs. 33-1, 2)

- To adjust the thread size, turn the mark on the Cam plate fixing pin closer towards you from the line on the size mark to make it larger, and in the opposite direction to make it smaller.




Fig. 33-1

Fig. 33-2

# Operation Guide (Cutting threads : Manual-open Die-head / NV-auto Die-head)

## 11. Cutting threads (Manual-open Die-head)

When using a Manual-open Die-head ( $\frac{1}{2}$  - 2"), (2  $\frac{1}{2}$  - 3"), check that the Die-head and Dies you are using are suitable for the pipe you are working on.

### ⚠ WARNING




- Start the thread cutting process with the Carriage to the right of the red line on the Carriage support bar A.
- If you start cutting a thread with the red line on the Carriage support bar A hidden from view, the Carriage could knock into the base, which could lead to damage or possible injury. (Fig. 34)
- If the machine happens to stop rotating in the middle of cutting a thread, turn the machine off immediately and pull out the plug. Failure to do so could result in fire or damage to the motor.

- To match the size of the thread, align the scale on the Eccentric handle (Fig. 32-1) with the thread size on the size scale on the Die-head, and then tighten and fix the Lever nut in position. (Fig. 34)
- Turn the machine on and oil will automatically flow from the Die-head.
- Turn the Carriage handle clockwise to engage the pipe with the Dies.
- Cut 3 or 4 threads and threading will then be performed automatically. (Fig. 35)
- The unit uses an universal motor whose rotation speed automatically varies according to the load.

- When the thread has been cut to the prescribed dimensions, slowly raise the Eccentric handle in the direction of the arrow and release the Dies to complete the threading process. (Fig. 36-1)

\*Note: If you release the Dies too abruptly, it may result in an imperfect finish such as a step-edged thread.

- Finally, complete the process by turning the Carriage handle anticlockwise to release the pipe from the Die-head. (Fig. 36-2)
- If you place the Die-head in the raised position, the flow of oil will stop.



## 12. Cutting threads (NV-auto Die-head)


### ⚠ CAUTION

To avoid accident or injury, always start the thread cutting process with the Carriage to the right of the red line on the Carriage support bar A.

- Loosen the Lever nut on the Die-head and match the marking on the Cam plate fixing pin with the pipe size on the Size plate; then retighten the Lever nut. (Fig. 37)

### ⚠ WARNING


- Start the thread cutting process with the Carriage to the right of the red line on the Carriage support bar A.
- If you start cutting a thread with the red line on the Carriage support bar A hidden from view, the Carriage could knock into the base, which could lead to damage or possible injury. (Fig. 34)
- If the machine happens to stop rotating in the middle of cutting a thread, turn the machine off immediately and pull out the plug. Failure to do so could result in fire or damage to the motor.



# (Cutting threads : NV-auto Die-head) Operation Guide

- Press down on the Open lever to put it into the 'Set' position. (Fig. 38)

- Switch the machine on and oil will start flowing automatically from the Die-head.




- Turn the Carriage handle to the right to engage the pipe with the Dies.

Cut 3 or 4 threads and threading will then be performed automatically. (Fig. 39)

- When the prescribed length of thread has been cut, the Dies will automatically be released by the Auto-open lever.

- Finally, release the Die-head from the pipe by turning the Carriage handle to the left.



## ⚠ WARNING

- When the NV-auto Die-head has finished cutting, it opens quite quickly. This may cause oil or small pieces of scrap to shoot out, which could possibly lead to injury.
- To avoid this, keep your hands and face away from the machine while it is going.

You can make shorter threads or any length of parallel threads, bolts etc., if you raise the Auto open lever at the length you want. When threading longer parallel threads, remove it as described below.

If the Die-head does not open automatically for some reason, such as scrap preventing it from opening, you can open the Die-head by raising the Open lever. (Fig. 38)

\*Note: Make sure the Die-head and Dies are appropriate for the type of thread that you wish to make; for example, threads for bolts etc.


### 1. Removing the Auto-open lever. (Fig. 40-1)

Loosen the Hex-socket cap screw (M6 x 12) and remove the Auto-open lever together with the Washer and the Spring washer.

\*Note: Make sure you do not lose any of the parts you remove. If you do, you will not be able to use the auto-opening function to cut threads of a regular length.

### 2. Resetting for regular tapered threading. (Fig. 40-2)

Adjust thread length by sliding the Auto-open lever B forward or backward.



# Operation Guide (Cutting threads : Uni-auto V Die-head)

## 13. Cutting threads (Uni-auto V Die-head)

Push the Cam plate up and set the Auto-open lever in position.  
As the Dies travel along the pipe, the end of the pipe comes into contact with the lever and pushes it out of its groove to release the Dies.

### ⚠ WARNING

- Start the thread cutting process with the Carriage to the right of the red line on the Carriage support bar A.
- If you start cutting a thread with the red line on the Carriage support bar A hidden from view, the Carriage could knock into the Base, which could lead to damage or possible injury. (Fig. 41)
- If the machine happens to stop rotating in the middle of cutting a thread, turn the machine off immediately and pull out the plug. Failure to do so could result in fire or damage to the Motor.




Fig. 41

### Setting the thread size

- Loosen the Lever nut and set the index line to the desired thread size and tighten firmly.

- Fit the appropriate Die-head as shown in Fig. 42.




Fig. 42

- Push the Cam plate handle forward to set the Auto-open lever then set the thread size by fitting the Lever nut to the appropriate position. (Fig. 42)

- Switch the machine on and oil will start flowing automatically from the Die-head.

- Turn the Carriage handle to the right to engage the pipe with the Dies.

Cut 3 or 4 threads and threading will then be performed automatically. (Fig. 43)



Fig. 43

- When the prescribed length of thread has been cut, the Dies will automatically be released by the Auto-open lever. (Fig. 44-1)

- Finally, release the Die-head from the pipe by turning the Carriage handle to the left. (Fig. 44-2)




Fig. 44

### ⚠ WARNING

- When the Uni-auto Die-head has finished cutting, it opens quite quickly. This may cause oil or small pieces of scrap to shoot out, which could possibly lead to injury.
- To avoid this, keep your hands and face away from the machine while it is going.

## 14. Cutting threads (Self-opening Die-head)

The FP80AV III comes with the NV-auto or Uni-auto Die-head (1/2 - 2"), Self-opening Die-head (2 1/2 - 3"), and 3 set of Dies (1/2 - 3/4"), (1 - 2"), (2 1/2 - 3") as standard accessories.

Check that the Dies you use match the size of pipe you are working on. The Dies used in the FP80A are suitable for threading coated steel pipes. Match the correct Die-head and Dies to the diameter of the pipe. Similarly, make sure you use the right Dies for stainless steel pipe.





### ⚠ CAUTION

Start the thread cutting process with the carriage to the right of the red line on the front support bar.

- Push the Die-head handle forward to set the Open lever then set the thread size by fitting the Size setting lever to the desired position. (Fig. 45)
- Switch on the machine and thread cutting oil will automatically flow out from the Die-head.
- Turn the Carriage handle to the right to advance the Die-head until the first two or three threads are cut. The rest is automatic. (Fig. 46)
- The Dies will automatically open when a perfect taper thread has been cut.
- Turn the Carriage handle to the left to clear the pipe. (Fig. 47)
- Push the Cam plate handle forward once again to set the automatic release. Reset the size if the next pipe is of a different diameter.

### ⚠ CAUTION

If the machine happens to stop rotating in the middle of cutting a thread, turn the machine off immediately and pull out the plug. Failure to do so could result in fire or damage to the motor. If you start cutting a thread with the red line on the Carriage support bar hidden from view, the Carriage could knock into the base, which could lead to damage or possible injury. (Fig. 48)



# (Cutting threads with the REX FP80A Series) Operation Guide

## Self-opening Die-head mechanism

Push the Cam plate handle (Fig. 45) up and place the Die-head in position for cutting threads.

As the pipe is cut, the pipe end comes into contact with Auto open lever A and continues to press up against it. Once the thread on the pipe has reached its prescribed length, the Cam plate connected to Auto open lever A opens automatically. The Dies retract from the pipe and threading is complete. (Fig. 49-1)

### ⚠ WARNING

When threading is completed, self-opening Die-heads open suddenly. There is a possibility of oil splashing out or metal shavings flying out, which might result in accident or injury. Avoid placing your hands or face too close to the machine.

## Adjusting the length of the thread (Figs. 49-1, 2)

- Press Auto open lever A, put the Dies in the open position, and loosen the socket head cap screw a little.
- Adjust the Auto open lever according to the length of the thread to be cut, i.e. towards the reamer for long and towards the cutter for short threads.
- Tighten the socket head cap screw securely again.

<b>Adjustable capacity</b>	1 - 3" (1 thread)
	½ - ¾" (1.3 threads)

## Microfine Adjustment of Thread Thickness (Fig. 50)

Microfine adjustment of thread thickness allows pipes to be cut exactly to your own requirements.

Simply turn the microfine adjustment knob to the left to decrease, and to the right to increase thread thickness.

\*The knob is locked by a locking bolt which should be loosened with the hexagonal key provided and the knob turned three settings to the right before adjustments are made.

<b>Adjustable capacity</b>	1 - 3" (1.5 threads)
	½ - ¾" (2 threads)

### ⚠ CAUTION

Size should always be checked with a thread gauge after adjustment.

## Adjustment of Thread Depth (Figs. 51, 52)

If, even with full adjustment, thread size is not satisfactory, remove the Retaining pin and reinsert the Size adjustment plates.

Hold in place with the Retaining pin.

- Pull up the Auto open lever (Fig. 49-1), and, with the Die-head open, loosen the Retaining pin with a flathead screwdriver.
- Hold on to the Size setting plate and remove the Retaining pin.
- Be careful not to let and the Notch pin and spring under the Size setting lever fly out.

\*If the Notch pin and spring under the Size setting lever fly out, replace in the hole on the Opening block.





- For thinner threads (Fig. 52-2) :

Move Size adjustment plate (b) into the position indicated by the arrow, and place together with plate (a) at the front of the groove in the Opening block. Lock in position by pressing down on the Notch pin and spring with the Size setting lever.

For thicker threads (Fig. 52-1) :

Move Size adjustment plate (a) and place together with plate (b) at the rear of the groove in the Opening block. Lock in position by pressing down on the Notch pin and spring with the Size setting lever.

- In the case of 2½ - 3" pipes only, while locked in position as in 4 above, first place the Pin with spring back in its hole, and then push the Retaining pin back in turn through the hole in the Opening block, Size adjustment plates (a) and (b), the Pin stop plate and the Size setting lever.
- Finally, tighten the Retaining pin securely with a flathead screwdriver.



## 15. Adjusting the oil flow

### ⚠ CAUTION

Do not adjust the oil flow while the machine is rotating.

You can adjust the oil flow from the Die-head.

- With the Die-head in threading mode, remove the Oil pan and check the discharge of the oil.
- Turn the Relief valve to adjust to the most suitable amount of oil needed. (Fig. 53)
- Rotating the valve clockwise decreases the oil flow; turning in the opposite direction increases it.  
Oil flow should not be adjusted while the machine is running.

\*Note: Depending on the load when threading, the amount of oil will vary according to the speed the machine rotates.




Fig. 53

## 16. Measuring threads with a gauge

### ⚠ WARNING

Threads may be affected by the condition of the Dies (blades), Cutting oil etc., so be sure to use a Thread gauge to check the thread. This is especially important after you have changed a set of the Dies.

### Confirming the thread diameter (Figs. 54, 55)

- Use a thread gauge to confirm the diameter is as it should be.

#### Thread gauge




Fig. 54

#### Other pipe thread gauges




Fig. 55

### Confirming the number of threads

- Confirm whether the thread length is as it should be according to the number of threads as shown in Fig. 56.

### ⚠ CAUTION

Choose an appropriate method for checking the threads on joints and other connections, such as using sealants, washing the joint, checking the torque etc.

#### Counting the number of threads










Fig. 56

# Operation Guide (Measuring threads with a Gauge)

## Unacceptable threads

- Irregular shaped threads (Fig. 57-1)
  - Recognising irregular shaped threads
    - a. Visually inspect the thread after wiping off any oil or dirt with a rag; you will find a wave-like formation.
    - b. Gently check the surface of the thread with your fingers, feeling for any irregularity.
    - c. Check if bits of scrap are produced when cutting.
- The diameter of the thread is too small or too large (Fig. 57-2)
  - Check with a Thread gauge.
- Distorted threads (in the case of Manual Die-head) (Fig. 57-3)
  - When cutting threads that are longer than the width of the Dies, you can gradually open up the Eccentric handle; but then if you leave the Eccentric handle in the same position and cut a thread longer than the width of the Dies, the taper will remain the same width as the Die and the rest of the thread will be straight.
- Threads are too thin (Fig. 57-4)
- The thread is chipped (Fig. 57-5)
- Thread with uneven thickness (Fig. 57-6)

<p><b>Correct thread</b></p> 
<p><b>1. Polygonal thread</b></p>  <p style="text-align: right;">Fig. 57-1</p>
<p><b>2. Small dia. / Large dia.</b></p>  <p style="text-align: right;">Fig. 57-2</p>
<p><b>3. Inflected thread</b></p>  <p style="text-align: right;">Fig. 57-3</p>
<p><b>4. Thin crests</b></p>  <p style="text-align: right;">Fig. 57-4</p>
<p><b>5. Chipped-off crests</b></p>  <p style="text-align: right;">Fig. 57-5</p>
<p><b>6. Biased wall thread</b></p>  <p style="text-align: right;">Fig. 57-6</p>

# Optional Accessories

## Die-head

Manual DH	For Steel pipes and Bolts	$\frac{1}{4} - \frac{3}{8} + W \frac{5}{16} - \frac{7}{8}, \frac{1}{2} - 1\frac{1}{2} + W1 - 1\frac{1}{4}$
	For Bolts	UNC $\frac{5}{16} - 2, M8 - 52$
	For Conduits (Thicker, Thinner)	PF16-82(BSPP : G $\frac{1}{2} - 3$ ) +C19-75
Self-opening Die-head		$\frac{1}{2} - \frac{3}{4}, 1 - 2, 2\frac{1}{2} - 3$

Table 3

## Dies

For Steel Pipes	BSPT	Alloy	$\frac{1}{4} - \frac{3}{8}, \frac{1}{2} - \frac{3}{4}, 1 - 2, 2\frac{1}{2} - 3$
		HSS	$\frac{1}{4} - \frac{3}{8}, \frac{1}{2} - \frac{3}{4}, 1 - 2, 2\frac{1}{2} - 3$
	NPT	Alloy	$\frac{1}{4} - \frac{3}{8}, \frac{1}{2} - \frac{3}{4}, 1 - 2, 2\frac{1}{2} - 3$
		HSS	$\frac{1}{4} - \frac{3}{8}, \frac{1}{2} - \frac{3}{4}, 1 - 2, 2\frac{1}{2} - 3$
For Conduit		Thicker conduit	PF16 - 22, PF28 - 36, PF42 - 54, G(BSPP) $\frac{1}{2} - \frac{3}{4}, G(BSPP)1 - 2,$ G(BSPP) $2\frac{1}{2} - 3, PF70 - 82$
		Thinner conduit	C19 - 25, C31 - 51, C63 - 75
For Bolt	BSW	Alloy	$W\frac{5}{16}, W\frac{3}{8}, W\frac{7}{16}, W\frac{1}{2}, W\frac{5}{8}, W\frac{3}{4}, W\frac{7}{8}, W1, W1\frac{1}{4}$
		HSS	
	UNC		$\frac{5}{16}, \frac{3}{8}, \frac{7}{16}, \frac{1}{2}, \frac{5}{8}, \frac{3}{4}, \frac{7}{8}, 1, 1\frac{1}{4}, 1\frac{1}{2}, 2$
	Metric	Alloy	M8, M10, M12, M14 - 16, M18 - 22, M24 - 27, M30 - 33, M36 - 39, M42 - 45, M48 - 52
HSS			

Table 4

## Parts for Single layer plastic coated steel pipes

Cutter Roller	Roller Blade
---------------	--------------

Table 5


## Pipe support: Hi-support (No.170051) \*See Pg. 10, Fig. 22

## Cutting oil:

- Miyagawa 50W-R (4L / 16L) : Water mains
- Miyagawa 246-R (4L / 18L) : General plumbing
- Miyagawa 100SW-RN (4L / 16L) : For Stainless Steel pipe only

## Nipple attachments

- REX Nipple Attachments are designed to be used together with our pipe threading machine to produce nipples easily. (Fig. 58 -1, 2)
- Refer to Minimum Length of Nipples (Table 6) to select the appropriate size.
- Refer to the Nipple Attachment Operation Manual for how to use Nipple attachments.



Minimum Length  
of Nipples




Fig. 58-1

Fig. 58-2

Size	* $\frac{3}{8}$	$\frac{1}{2}$	$\frac{3}{4}$	1	$1\frac{1}{4}$	$1\frac{1}{2}$	2	$2\frac{1}{2}$	3
Weight (kg)	1.5	1.5	1.5	1.5	1.9	1.9	2.8	3.2	3.5
Minimum length of Nipples (mm)	55	45	50	55	65	65	70	75	80

\*BSPT only.

Table 6

# Maintenance and Care

## ⚠ WARNING

- Before inspecting or performing maintenance on the unit, always set the Switch to the OFF position and remove the plug from the power outlet.  
If the unit is left plugged in, it may begin operating unexpectedly, resulting in injury.
- If you discover any problems during inspection or maintenance, look up the symptoms in the "Troubleshooting" table and take the appropriate action as noted in the table.  
Continued use of the unit without correcting the problem may result in heat, smoke or fire and lead to accident or injury.


## 1. Grease, Oil

### Greasing the Main shaft bearing

- Be sure to apply Grease to the Main shaft and bearings about once a month. (Fig. 59-1)

### Oiling the Cutter

- Before you operate the machine, be sure to maintain lubrication by applying spindle oil or machine oil to the thread on the Cutter handle, Roller shafts and the Cutter wheel once a day. (Fig. 59-2)



## 2. Replacing the Carbon Brushes (Figs. 60, 61)


- To protect the Motor, the unit is equipped with auto-stop Carbon brushes.  
When these brushes get too worn, the Motor will not operate even when the unit is turned on.
- Be sure to use REX Carbon brushes.  
Using other brushes may damage the Motor.

### Replacing the Carbon brushes

Ensure the plug has been removed from the power outlet.  
Always replace both brushes at the same time.


#### How to replace the carbon brushes

1. Remove the four bolts from the rear cover. (Fig. 60)
2. Remove the carbon brush caps using a flathead screwdriver, and replace the carbon brushes. (Fig. 61)



## ⚠ WARNING

- Be sure to use REX Carbon brushes.
- Using other brushes may damage the Motor or the machine, or cause accidents.




## 3. Cleaning the Tank

As tiny bits of scrap accumulate in the Tank, be sure to clean it at least once a month. (Fig. 62)

\*Note: There should be 4 liters of Cutting oil in the Tank.  
Use REX Cutting oil only.

### Cleaning the Tank

- First, remove the Scrap tray, then lift up the Tank upper cover using the Finger grip and remove it. (Fig. 62)
- Remove the Strainer by using a phillips screwdriver to loosen the Round head screw that fastens the Oil tube to the Strainer.
- Remove the Drain plug and drain off the Cutting oil.
- Replace the Drain plug once all the scrap in the Tank has been removed. Put the Strainer back before replacing the Cutting oil.





## 4. Structure and care of the Chuck jaw set



As shown in Fig. 51, Chuck jaw insert set consists of 4 parts: the Chuck jaw insert at one end of the Chuck jaw, and the Spring retainer, Spring, and Set screw at the other.

When changing the Chuck jaw insert, turn the Hand wheel so that the indent is directly over the Chuck jaw and remove the Set screw inside it. (Fig. 63)

Also, if the 6 bolts that fix the Chuck in position come loose, it will affect thread cutting, so check regularly and tighten as needed.



## 5. Wiring diagram



# Servicing and Repairs

This machine is produced with great precision; therefore, should the machine fail to operate normally, do not repair it by yourself; contact your distributor, dealer or REX INDUSTRIES CO., LTD.

If parts are required or if you have any questions, please contact us at your earliest convenience.

Availability of Replacement Parts	Replacement parts are maintained for a period of 7 years after production of this model has been terminated. Electrical parts, however, will remain available for a period of 5 years.
-----------------------------------	---

## ⚠ WARNING

- If the problem you have and the appropriate remedy are not shown in the table below, do not attempt to disassemble or repair the unit yourself.
- If the problem and remedy are not shown in the table, or if the table indicates that you should have the unit repaired or serviced, consult your distributor, dealer or REX INDUSTRIES CO., LTD.
- If this product is repaired by someone who does not have the proper knowledge or technical skill to do so, the product may not operate properly, or an accident or injury may occur. In the event of a problem, always check the table before contacting your distributor, dealer or REX INDUSTRIES CO., LTD.

## Troubleshooting

Problem		Cause	Remedy
Machine does not operate properly when turned on.	The Motor is not running.	The plug is disconnected.	Insert the plug into the power socket.
		The Carbon brushes are worn.	Replace with new ones according to the procedures on Pg. 22.
		Voltage is low.	Check the voltage. (Pg. 10)
		The Motor is burned out.	Repairs are needed.
	The Motor is running.	The Switch is damaged.	Repairs are needed.
		The Gear is broken.	Repairs are needed.
Rotation of the main shaft is defective.		Voltage is too low.	Check the voltage. (Pg. 10)
		The Motor is burned out.	Repairs are needed.
No oil flow.		Amount of oil is too low.	Replenish oil.
		Scrap clogging the flow.	Remove scrap in the Oil tank.
		The Die-head is not fitted correctly.	Fit the Die-head in the correct position.
Oil flows out of the back of the pipe.		Rear chuck is set too low.	Raise the Rear chuck.
Difficulty in attaching the Die-head.		Scrap is in the way.	Remove scrap attached to the Die-head post and hole.
		Die-head is obstructed by cut-off pipe etc. on top of the Tank cover.	Remove the obstruction.
Moving parts do not move smoothly.		Moving parts blocked by scrap.	Remove scrap.
Dies do not engage pipe correctly.		The Dies are worn.	Replace with new ones.
		The Dies are chipped.	Replace with new ones.
		The Dies are not inserted in the correct position.	Match the Dies to the number on the Die-head.
Threading cannot be performed correctly.	Too Large / Small	The Die-head is not adjusted correctly.	Adjust the Die-head according to the procedures on Pgs. 13 - 15.
		Too Long / Short	The Die-head is not adjusted correctly.
		The Dies are worn.	Replace with new ones.
		The Dies are chipped.	Replace with new ones.
		Thread Cutting oil has deteriorated.	Replace with new oil.
		The Dies are not inserted in the correct position.	Match the Dies to the number on the Die-head.

Table 7

# Explanation of Symbols

## Explanation of Symbols

	<b>SAFETY INSTRUCTIONS</b> Read and understand the Operation Manual before using the machine.
	<b>RISK OF EAR INJURY</b> Wear an ear protection.
	<b>RISK OF EYE INJURY</b> Wear an eye protection.
	<b>LIFTING HAZARD</b> Heavy object - mechanical lift only
	<b>ELECTRICAL HAZARD</b> This machine is to be operated by trained personnel only.
	<b>CRUSH HAZARD</b> Moving parts can cause serious injury. Keep hands clear while operating.
	<b>ROTATING ROLLERS HAZARD</b> Keep hands and fingers clear.
	<b>CUT HAZARD</b> Sharp edges can cause serious injury. Keep hands and fingers clear.

Table 8

## **Guarantee and Exemption from Liability**

1. Should the machine happen to break down for no apparent reason, despite normal and correct use, repairs and service parts shall be provided free of charge as outlined below.

Repairs shall be provided free of charge for a period of one year from date of purchase.

Dates, procedures and methods for providing repairs and service parts shall be decided in consultation with the customer.

After the one-year guarantee period, all repairs and service parts will be charged.

Repairs may be charged even within the guarantee period under the following circumstances:

- if the machine has not been used according to the instructions in the Operation Manual
  - if it has been used for anything other than its intended purpose
  - if it has not been repaired according to the Operation Manual or if it has been remodeled
  - if blades or consumables need replacing
  - if the machine has been handled in an inappropriate way.
2. REX will accept no responsibility under the following circumstances:
    - if a malfunction or accident occurs as a result of fire, abnormal fluctuations in voltage, damage from flood, earthquakes, lightning or other natural disasters, war, conflict, riot, terrorism or pollution, etc.
    - when the machine has not been operated according to the Operation Manual
    - when the machine has been used incorrectly, repaired or remodelled inappropriately
    - when a malfunction or accident results from using a thread made on the machine, or leaving it lying around and/or if it is exposed to the elements
    - when a malfunction or accident results from using a thread produced on the machine either while or after connecting it to a joint.
  3. Any costs incurred by the manufacturer shall not exceed the purchase price of the machine.

# **REX**

## **REX INDUSTRIES CO., LTD.**

Overseas Sales Dept. & Factory :

1-9-3, Hishiya-Higashi, Higashi-Osaka 578-0948 Japan

Tel. +81 - (0)72 - 961 - 9820 Fax. +81 - (0)72 - 961 - 9878

URL <https://www.rexind.co.jp>

8A48-CE2

FP80A

2505H0100