



**REX**

PIPE THREADING MACHINE

# N100A Series

## OPERATION MANUAL



 Be sure to read this Operation Manual before using the machine.

- Note -

- Be sure to hand this operation manual to the user.
- To ensure safe and efficient use, read the manual thoroughly before using the machine.
- Be sure to keep the manual where the operator can refer to it whenever necessary.

Date of purchase:	Year	Month
Distributor:		

Thank you for purchasing a REX pipe threading machine.

Precision-engineered for cutting, reaming, threading and, with our optional Portable Groovers, grooving steel and stainless steel (option) pipes, our product will give you years of reliable service if you simply follow the instructions in this manual carefully.

Before using the machine, therefore, make sure you read the manual from start to finish, paying particular attention to the Safety Considerations on pages 1 & 2 and Precautions on pages 3 & 4. To avoid accident and injury, never use the machine for any purposes other than those described in this manual.

Should you need further advice, contact your distributor or REX Industries Co., Ltd.

---

## CONTENTS

---

Safety Considerations .....	1
Precautions .....	3
Main Parts, Specifications, Standard Accessories, Usage.....	5
Getting Ready	
1. Transportation .....	6
2. Setting up .....	6
3. Cutting oil .....	6
4. Attaching the die head .....	6
5. Operating the die Head .....	7
6. Setting up the pipe • Removing the pipe .....	10
7. Power supply .....	10
8. Using the speed change lever .....	11
9. Checks before starting/Using the Foot switch (CE) .....	11
10. Cutting pipes .....	12
11. Reaming .....	13
Operation Guide	
12. Cutting threads (Manual-open Die Head) /Precautions when threading.....	14
13. Cutting threads (Uni-auto V Die Head) .....	15
14. Cutting threads (Profiling Die Head) .....	16
15. Measuring threads with a gauge .....	19
Optional Accessories .....	20
Maintenance and Care	
1. Grease, Oil .....	21
2. Adjusting the V-belt .....	21
3. Cleaning the oil tank .....	21
4. Structure and care of the chuck jaw set .....	22
5. Wiring diagram .....	22
Servicing and Repairs .....	22
Troubleshooting .....	23

---

Definitions of **⚠ WARNING** and **⚠ CAUTION**

In this operation manual, warnings are divided into **⚠ WARNING** and **⚠ CAUTION** .

**⚠ WARNING** : indicates actions which could possibly result in death or severe injury to the user if the machine is used incorrectly.

**⚠ CAUTION** : indicates actions which could possibly result in injury to the user, or physical damage, if the machine is used incorrectly.

Even items labelled **⚠ CAUTION** could have serious results under certain conditions.

Be sure to observe these warnings carefully as they greatly affect safety.

- If this operation manual is lost or damaged, promptly order a replacement from your distributor or our sales department.
  - Parts and specifications are subject to change without prior notice, due to improvements in quality, performance or safety standards. In such cases, the contents, photographs, illustrations, etc. in this manual may be different to the product you have purchased.
-

# Safety Considerations

## ⚠ WARNING

### 1. Ensure you use the correct voltage.

- Be sure to use the voltage indicated on the name plate of the main unit or in the operation manual. If the voltage is different from the voltage indicated, overheating, smoke or fire may occur.

### 2. Check the switch is OFF before inserting the plug into the power supply socket.

- If the plug is inserted into the power supply when the switch is ON, the machine may start operating abruptly and is liable to cause accidents. Be sure to check the switch is OFF.

### 3. Be sure to avoid electric shock.

- Do not touch the plug with wet hands.
- Do not use the machine in rain or in places where moisture can easily get into the machine.
- Be sure to ground the machine to avoid electric shock.

### 4. Take notice of conditions at the work site.

- Do not use the machine in rain, humid or damp places, or places where moisture can easily get into the machine. Humidity will lower insulation of the motor and cause electric shock.
- Do not use close to flammable fluids or gases, such as gasoline and thinner. Fire or explosion might occur.

### 5. Use designated accessories and attachments.

- Do not use accessories and attachments other than those designated in the operation manual or our catalogues. Accidents or injuries might result.

### 6. In the following cases, turn the main unit OFF and pull the plug out of the power supply socket.

- When the machine is not in use or parts are changed, repaired, cleaned or inspected.
  - When accessories are changed.
  - When hazards are expected (including electric power failure).
- If the machine is plugged in, it may start operating unexpectedly, causing accidents.

### 7. If any abnormality is noticed, stop operation immediately.

- If the machine does not operate smoothly, or abnormalities such as unusual odours, vibration or noise are detected, stop operating the machine immediately.
- Check symptoms against the items in the section entitled, "Troubleshooting" at the end of this manual and observe the corresponding instructions. If the machine is used continuously, overheating, smoke or fire might occur, causing accident or injury.
- If overheating or smoke from the unit occurs, do not attempt an overhaul yourself but ask for an inspection and repair.

### 8. Keep the work site clean.

- Ensure you keep the work table and the work site in good order and well lit.
- A cluttered site and work table are liable to cause accidents.

### 9. Do not let unauthorised personnel near the machine.

- Do not let anyone other than authorised personnel touch the main unit or the power cord, or operate the machine.
- Do not let anyone other than authorised personnel enter the work site, especially children. Injuries might occur.

### 10. Do not use the machine with excessive force.

- To ensure safe and efficient operation, use within the capacity of the main unit. Applying force may not only cause damage to the product but could also result in accident or injury.
- Do not use the machine in any way that could cause the motor to lock, or cause smoke or fire.

### 11. Use the machine only for its designated purpose.

- Do not use the machine on pipes not specified in this manual. Using the machine for any purpose other than threading pipes, such as fastening the pipe to a joint etc., will not only damage the machine and/or motor but could also lead to accident or injury.

## ⚠ WARNING

### **12. Wear appropriate clothing.**

- Do not wear neckties, clothes with unbuttoned sleeves, loose clothing, accessories such as necklaces, etc. Do up buttons and zippers which could get caught in the rotating parts and result in serious accident or injury.
- When working outdoors, it is recommended that you wear rubber gloves and non-slip shoes. Slippery gloves and shoes are liable to cause injuries. (Refer also to point 4, Pg.3)
- Do not wear scarves and cover long hair with caps or hair nets to prevent them getting caught in rotating parts.
- Wear safety caps, safety shoes, etc. according to the working environment.

### **13. Do not work in an unnatural posture.**

- Keep a firm footing and balance to avoid falling over and injuring yourself.

### **14. Remove tools such as wrenches.**

- Before turning the switch ON, check that tools used for inspection and adjustment have been removed. If you use the machine when tools are left inside it, accidents and injuries may occur.

### **15. Operate the unit with great care.**

- Always work with great attention to how you handle and operate the machine and to the surrounding conditions. Carelessness may result in accident or injury.
- Do not operate the machine when concentration is lowered such as when tired, after drinking alcohol, when sick, affected by medicines, etc.

### **16. Do not handle the power cord carelessly.**

- Do not carry the product by the cord, or pull the plug out of the socket with the cord.
- Do not place the cord near heated objects, fats & oils, cutters and objects with sharp edges.
- Take care not to tread on the cord, pull the cord or apply unnecessary force resulting in damage to the cord. Electric shock or short-circuit may occur, causing fire.

### **17. Perform careful maintenance daily.**

- When changing accessories and parts, follow the operation manual. Periodically inspect the power supply cord and plug. If damaged, ask your distributor or our sales department for repairs.
- If an extension cord is used, inspect the cord periodically and, if damaged, replace it.
- If extension cords are used outdoors, use extension cords designed for outdoor use to prevent electric shock, short-circuit or fire.
- Keep parts used for gripping dry and clean, and free of oil and grease. If your hands slip, you may be injured.

### **18. Check for damaged parts.**

- Before using the machine, carefully check for damage to the protective cover and other parts, and check both normal operation and specified functions.
- Check for any abnormalities such as in adjustment of movable parts, tightening, damage to and installation of parts and all parts affecting operation.
- Do not use machines with a damaged power cord or plug. Doing so may cause electric shock or a short, circuit leading to fire.
- Do not use machines if the stop and start switches do not work properly. In replacing or repairing a broken protective cover and other parts, follow the operation manual. If no instructions are specified in the operation manual, ask your distributor or our sales department for repairs.

### **19. Store carefully when the machine is not in use.**

- Store in a dry place away from children and locked with a key.

### **20. For overhaul and repair of the machine, ask an appointed REX agent.**

- Our products comply with corresponding safety standards. Do not remodel.
- Be sure to ask your distributor or our sales department for any repairs. If repairs are carried out by unskilled or unqualified personnel, the performance of the unit will be adversely affected and may result in accident or injury.

# Precautions

## Threading

### ⚠ WARNING

#### 1. Take care when handling the blades.

- To prevent accidents and injuries, take special care when handling blades such as dies, reamers, pipe cutters and carbide cutters.

#### 2. Do not put your hands or face near rotating parts when the machine is in use.

- You could get caught in rotating parts or hit by scrap, resulting in accident or injury.

#### 3. Do not perform the next job until rotation stops completely.

- When you turn the switch off, rotation does not stop immediately. Perform the next job only after checking that the machine has come to a complete stop. Failure to do so may result in accident or injury.

#### 4. Avoid wearing gloves that could get caught up in the rotating parts of the machine.

- Be careful if you wear gloves when threading. String gloves, woolen gloves or the like can get caught in rotating parts leading to serious injury. Choose your gloves very carefully.

#### 5. Do not leave the machine while it is still rotating.

- Others may be injured.

#### 6. If you accidentally drop or hit the machine, carefully check for damage, cracks, deformities or any abnormalities.

- If abnormalities are found, ask your distributor or our sales department for an inspection and/or repair.
- Continuing to use the machine when damaged will likely lead to mechanical problems, accident or injury.

#### 7. Do not touch the dies or scrap just after threading.

- The dies and scrap can become very hot just after threading; touching them could burn or injure you.

#### 8. Die head and dies.

- Use the die head and dies that are appropriate for the type and diameter of pipe to be processed.
- When threading stainless steel pipes use pipes with a wall thickness equivalent to Schedule 40 or more.
- Make sure the die head is mounted correctly on the carriage. Be careful not to get your fingers caught.
- Before you start threading, set the die head in the threading position, switch ON, and check that the oil is flowing correctly over the dies. Failing to do so could result in an imperfect thread, damage to the machine, accident or injury.

#### 9. Be sure to check the starting position before threading.

- When threading, start with the carriage to the right of the red line on the front support bar (as viewed from the working position).

If the carriage is not in the correct starting position, the die head will bang into the main unit while threading, causing mechanical problems, accident or injury.

#### 10. Use the pipe support when threading long pipes.

- When threading long pipes, use a pipe support to prevent both vibration due to warping while the pipe is rotating and instability of the machine due to the weight of the workpiece.

If a pipe support is not used, threading cannot be performed correctly and problems with the machine, accident or injury may occur.

#### 11. Be sure to attach accessories according to the operation manual.

- Attaching accessories incorrectly may cause the machine to topple over resulting in accident or injury.

## Reaming

### ⚠ WARNING

The reamer blade is very sharp; to prevent injury, avoid touching it with bare hands.

## Cutting

- Using the Pipe Cutter

### ▲ CAUTION

When cutting pipes, turn the cutter handle no faster than ½ rotation per rotation of the pipe.  
- If the cutter handle is turned too quickly when engaging the pipe, it can distort the shape of the pipe and may not make a proper thread.

## Handling pipe threading oil

### ▲ WARNING

1. Wear goggles.
  - Touching the eyes with oil may cause inflammation.
  - Emergency treatment : Wash eyes with clean water for about 15 minutes and seek medical attention.
2. Wear protective gloves.
  - If oil comes into contact with the skin, it may cause inflammation.
  - Emergency treatment : Carefully wash the affected part with soap and water.
3. Take care not to breathe in oil mist or steam.
  - Breathing in oil mist or steam may cause nausea.
  - Emergency treatment : Carry the person out into the fresh air, cover them with a blanket, keep them warm and relaxed, and seek medical attention.
4. Do not thin the oil or mix it with threading oil produced by other companies.
5. If water gets mixed in with the threading oil and the colour changes to a milky white or the oil deteriorates excessively resulting in a poor finish, change to fresh oil promptly.
6. Do not drink the oil.
  - Drinking the oil may cause diarrhoea or vomiting
  - Emergency treatment : Seek medical attention immediately, without forcing the person to vomit.
7. Do not place the oil where it is easily reached by small children.
8. Be especially careful of fire.
9. Storage.
  - Always close the lid after use to prevent the oil from being contaminated by dust, water or other foreign bodies.
  - Store in a dark place away from direct sunlight.

## When using threading oil for water mains pipes and water-immiscible cutting fluid for threading

### ▲ CAUTION

1. Handling waste oil and waste cans.
  - Handle materials according to local laws and regulations regarding waste disposal and cleaning.
  - If uncertain, consult your distributor or our sales department.
2. Drums (200L).
  - To prevent them from bursting, do not apply pressure to empty drums.
  - Do not weld, heat, drill or cut the drums or they may burst into fire from the residue they contain.

## When using threading oil for stainless steel pipes

### ▲ WARNING

1. Do not burn off the oil.
  - Oil contains chlorine compounds and generates toxic gas when burnt.  
In the case of an emergency in which someone has inhaled such toxic gases, carry the affected person out into the fresh air and seek medical attention.
2. Disposal of waste oil and cans.
  - Follow all laws and regulations related to the disposal and cleaning of waste materials. When uncertain, consult your distributor or our sales department.

# Main Parts, Specifications, Standard Accessories, Usage

## Main Parts




Fig. 1

## Specifications

		N100A Series	
Threading capacity	½"(15A) - 4"(100A)		
Type of thread	Standard Taper Pipe Thread		
Voltage	110V - 120V, 220V - 230V, 110 / 220V		
Motor	Single phase 750W or 1KW condenser motor		
Rotation speed	Shifting	Frequency:	50Hz or 60Hz
	½ - ¾" threading, cutting, reaming		48 r.p.m. (unloaded)
	1 - 2" threading		27 r.p.m. (unloaded)
	2½ - 4" threading		15 r.p.m. (unloaded)
Net weight	127.5Kg		
Dimensions	803mm (L) X 470mm (W) X 558mm (H)		
Chuck type	RT-type chuck, RS-type or RT-type chuck jaw insert		
Minimum length of pipe (mm)	½" (15A) : 125mm 4" (100A) : 170mm		

Table 1

## Standard Accessories

		N100A Series	
Die head	Manual or Uni-auto (½ - 2") / Profiling (2½ - 4")	One each	
Dies	(½ - ¾") (1 - 2") (2½ - 4")	One set each	
Cutting oil	Miyagawa 246-R	1 can (4L)	
Pipe stands / leg caps		4 / 4	
Machine cover		1	
Screw driver	(+)	1	
Hexagonal keys	3, 4, 5, 6, 8 mm	1 each	
Adjustable wrench		1	

Table 2


**Usage:** Cutting, reaming, threading steel and stainless steel pipes. Also with our optional dies and die heads for bolt, threading steel round bars and with our optional Portable Groovers, grooving.

# (Transportation / Setting up / Cutting oil / Attaching the die head) Getting Ready

## 1. Transportation

When moving or transporting the machine, there is no need to drain off the cutting oil in the tank. (Fig. 2)

- Before moving the machine, chuck a piece of pipe securely and fix it in place with the cutter so that the carriage does not move.




## 2. Setting up

Place the machine on a flat surface. (Fig. 3)  
Even when placed on a flat surface, the rear chuck of the machine is designed to be in a slightly raised position.

### ⚠ WARNING

If the rear chuck is too low, oil will flow out of the pipe, making the floor dirty and wasting oil.

Once the machine is set up, be sure to place the oil pan in its correct position.




## 3. Cutting oil

Fill the tank with the cutting oil that is supplied with the machine.  
Use only genuine REX cutting oil. (Fig. 4)

- For stainless steel pipe only "Miyagawa 100SW-R" (Black can)
- Water washable "Miyagawa 50W-R" (Blue can)
- Standard "Miyagawa 246-R" (Red can)

### ⚠ WARNING

Miyagawa 100SW-R cutting oil for stainless steel pipe can only be used for threading stainless steel pipe. Using this oil for threading pipes made of other materials may result in irregular threads.




## 4. Attaching the Die head

Attach the die head that matches the size of pipe to be threaded to the machine. (Fig. 5)

Attach the die head to the machine.


- Align the die head post to the carriage fitting hole, and push it until it contacts the carriage while moving the die head up and down a little.
- Lower the die head and check it is positioned correctly.

\* Remove the die head by following the above in the reverse order.



# Getting Ready (Operating the die head)

The N100A carriage has two fitting holes for die heads of different sizes. (Fig. 6)  
Insert the die head into the appropriate hole and move the die head holder into the appropriate position. (Fig. 7)  
Turn the oil flow selector to the correct position.




## 5. Operating the Die Head

### Manual-open die head

(There is no need to remove the die head from the machine.)


### Removing the dies

- Knock the eccentric handle to the right, loosen the lever nut and push the eccentric handle over to the far left. (Fig. 8)
- In this position, dies No. 3 and No. 4 can then be removed.
- Raise the die head and you can remove dies No. 1 and No. 2.



### Replacing the dies

- Ensure the number on the dies corresponds with the number of the slot on the die head. Insert each die until the notch is engaged. (Fig. 9)
- Pull the eccentric handle back in the opposite direction, left of the arrow. (Fig. 8) The dies will move towards the centre of die head.
- \* If the eccentric handle does not move into position properly, move the dies up and down a little while pushing and pulling the eccentric handle gently and try again.
- \* Dies are made as a matched set of four, so be sure to use them as such and replace them all at the same time. Do not attempt to replace just one or two of the set, as cutting will be adversely affected.




## Uni auto V Die Head

(There is no need to remove the die head from the machine.)


### Removing the Dies (Figs. 10, 11)

Push auto-open lever A in the direction of the arrow (Fig. 10-1) and put the die head into the open position.

Loosen the lever nut by turning in the direction of the arrow (10-2) and fully turn the cam plate in the direction of the dies-open position. (Fig. 10-3)



Remove the dies from the die head. (Fig. 11)






### Replacing the Dies (Figs. 12, 13, 14)

Insert each die into its corresponding slot number in the die head as far as the line marked on the die. (Fig. 12)

Turn the cam plate in the direction of the die-set (Fig. 13-1) and tighten the lever nut on the appropriate pipe size position. (Fig. 13-2)

Next, push the cam plate upwards in the direction of the die-set and set in position. (Fig. 14)





# Getting Ready (Operating the Die Head)

## Profiling Die Head

(There is no need to remove the die head from the machine.)

## Removing the Dies

1. Remove the size setting lever from the size setting pin and move the lever as far as it will go in the direction of the arrow. (Fig. 15-1)
2. Move the profiling board to the right as shown in Fig. 15 (as when a thread has been competed), lower the die head until the roller comes into contact with the profiling cover, and then remove dies 1 and 2 from the top of the die head.
3. Next, pull out the pin on the die head release lever that holds the die head in place, and raise the die head as shown in Fig. 20. Then pull the die head handle towards you and remove dies 3 and 4.





## Replacing the Dies

1. Remove the size setting lever from the size setting pin and move the lever as far as it will go in the direction of the arrow.
2. Move the profiling board to the right as shown in the diagram (as when a thread has been competed) and lower the die head. Then insert dies 1 and 2 until they click into position in their respective die slots.
3. Raise the die head, pull the handle towards you and insert dies 3 and 4 into their respective slots in the die head.

### Important!

- \* Dies come in a unique set of 4. Always use die heads from the exact same set. Using a die from another set can result in imperfect threads.
- \* If a die does not fit into its slot smoothly, never force it. Always check for any foreign bodies, such as scrap etc., and then try again.




# (Setting up the pipe / Removing the pipe / Power supply) Getting Ready

## 6. Setting up the pipe / Removing the pipe

### ⚠ WARNING


- Do not install or remove a pipe when the machine is moving, such as when operating the machine or just after you switch it off. If you do, you may get entangled, leading to accident or injury. Start operation after you make sure the machine has come to a complete standstill.
- When installing or removing the pipe, remove the plug from the power outlet or the machine could suddenly start operating leading to injury or accident.

- Open the hammer chuck and rear chuck wider than the size of the pipe to be threaded and insert the pipe from the rear chuck side where possible. (Fig. 19) (In the case of a short pipe, insert a pipe from the chuck side.)
- Close the rear chuck and, holding the pipe in your right hand, close the hammer chuck with your left hand to place a grip lightly on the pipe and make sure the chuck jaw inserts engage the pipe properly. Pull the hand-wheel sharply towards you to lock.
- A sharp jerk in the opposite direction will release the pipe once you have finished threading. Next, remove the pipe after releasing the rear chuck.




### Suggestions for short pipes

- Lightly grip the pipe with the chuck, gently engage the dies with the end of the pipe to be threaded, and then tighten the hammer chuck again. (Fig. 20)
- Note: Chuck the pipe with the pipe protruding at least 90 mm from the edge of the chuck jaw insert. (Fig. 20)



### Suggestions for long pipes

- When threading long pipes, use a pipe support to avoid excessive vibration etc. while the pipe is rotating, and to prevent the machine from becoming unstable under the weight of the workpiece. (Fig. 21)



### Use the REX pipe support

Model: Hi-Support Code No.170050

Keeps long pipes stable.




Fig. 22

### ⚠ WARNING

Not using a pipe support may result in irregular threads, damage to the machine and/or accident or injury.

## 7. Power supply

Before using the unit, check the voltage on the nameplate. Use only an AC power supply. If an extension cord is used, it must be as short as possible and of sufficient capacity for the power supplied (at least 2mm<sup>2</sup> cabtyre cable, 20A for 110-120V and 10A for 220-230V). (Fig. 23)

### ⚠ WARNING

- Before connecting the plug to the socket, check that the machine switch is turned OFF to prevent abrupt movements that could lead to accident or injury.
- When you use a 110 - 120V power supply, ensure it is earthed or you may get an electric shock. If the power socket is already earthed, first remove the supplied adapter with the earth.




Fig. 23

# Getting Ready (Power supply / Operating the speed change lever / Checks before starting / CE Foot Switch)

## Changing between 110V and 220V : Option

### ⚠ WARNING

Always remove the plug from the power socket before switching from one voltage to the other.

1. Remove the cover of the voltage switch located on the front of the unit with a Phillips screwdriver.
2. Press the snap switch to select either 100V or 220V.
3. Replace the cover before use.

## 8. Using the speed change lever

Change the rotation speed as appropriate by placing the speed change lever in the position that matches the size of the pipe to be processed.

Work \ Speed	High	Medium	Low
Threading 1/2" - 3/4"	●		
Threading 1" - 2"		●	
Threading 2 1/2" - 4"			●
Cutting	●		

Table. 3




Fig. 24




Fig. 25

## 9. Checks before starting

### ⚠ WARNING

Carry out the following checks before starting to cut or thread pipes. Should any problems arise, refer to "Troubleshooting" at the end of this manual and follow the appropriate instructions. Continuing to use the machine when a problem has arisen can lead to accident or injury.

1. Turn on the machine to set the main shaft in motion. (Fig. 26)
  - Check there are no abnormal sounds or odours coming from the motor.
  - Check the pipe you installed does not vibrate abnormally. If it does, install it again.
  - Check that cutting oil flows as it should from the die head. Confirm that there is at least 1 liter of cutting oil in the tank. (tank capacity:3.5L)
2. Allow the machine to rotate without any load for several minutes.
  - Check the motor does not become abnormally hot, etc.
3. Turn the machine off and allow it to stop rotating.
  - Check that the motor stops rotating right away.




Fig. 26

## Using the Foot switch

To comply with EU regulations the unit incorporates a foot switch. The foot switch has a mechanism by which pressing down on the pedal turns the current on and releasing the pedal turns it off and stops the machine. (Fig. 27)

### Warning :

1. Place the foot switch in a position where it is easy to use, close to where you are working.
2. Be sure to switch Off if there is a sudden power cut. If you leave the machine on, then once the power comes back on the machine will suddenly start up, which could lead to accident or injury.
3. The machine will not start rotating unless both the On button and the foot switch have been engaged. However, once turned on, it is not necessary to keep pressing the On button each time.





Fig. 27


## 10. Cutting pipes

When cutting stainless steel pipes, use only the appropriate blade for cutting stainless steel (product No. 135077).

1. Raise the die head and reamer.
2. Position the pipe so that it is ready for cutting and fasten the pipe securely with the hammer chuck.
3. If not already visible, turn the cutter handle anti-clockwise until the red line appears.




4. Open the pipe cutter wider than the diameter of the pipe, lower it into position in the groove on the carriage.
5. Push the open lever bringing the cutter close to the position where the blade and roller lightly press against the pipe.




6. Switch the machine on and turn the cutter handle up to  $\frac{1}{2}$  a turn for each rotation of the pipe. (Fig. 30)

\*Note: If the cutter handle is turned too quickly, it will affect the shape and finish of the thread.



7. When cutting is completed, switch OFF.
8. Lower the open lever and pull out the cutter handle.
9. Turn the cutter handle to the left until the red line re-appears. Lift up the cutter unit.  
Note: If you can see the red line on the shaft and you try to turn the handle in an anti-clockwise direction again, you can damage the thread on the handle. Do not turn the handle any further once the red line is visible. (Fig. 31)



### **CAUTION**

Be sure to position the cutter correctly before the pipe starts rotating. If it is not in the correct position it could damage the pipe or the machine.

# Getting Ready (Cutting pipes / Reaming)

## Special precautions when you cut a pipe with another cutter

We strongly recommend that only the pipe cutter attached to the machine be used to cut pipes.

If another cutter is used, ensure that the pipe end is at right angles to the axis of the pipe. (Fig. 32-A)

If the pipe is not square on, as in Fig. 32-B and C, threads may be defective. B and C may be the result of the following:

### Fig. 32-B

- The bearing or chucking of the cutter is unstable.
- When a grinder is used with excessive force (especially in the case of large diameter pipes.)
- When the pipe is engaged at an angle when cutting.

### Fig. 32-C

- When you have cut a large diameter pipe 2 or 3 times with a small grinder.




Fig. 32

## ⚠ CAUTION

If the end of the pipe is slanted (Fig. 32-B) or has steps in it (Fig. 32-C), it is not only impossible to make a perfect thread, but may even result in damage to the machine, accident or injury.

## 11. Reaming

- After cutting the pipe with the pipe cutter, be sure to use the reamer to chamfer the inside of the pipe before making a thread. (Figs. 33, 34)

## ⚠ CAUTION

- Do not use excessive force when pressing the reamer against the pipe as this may scratch the pipe or even damage the machine.
- The reamer blades are extremely sharp. NEVER touch them with your bare hands, as you could be seriously injured.

- Lift the die head and cutter out of the way.

- Lower the reamer arm and set it in position on the carriage, then push the reamer knob toward the pipe. (Fig. 33-1)

\*Note: Reaming is possible without pushing the shaft when a pipe is chucked long enough from the chuck.

- Lock the reamer in position by turning the reamer handle anti-clockwise. (Fig. 33-2)

- Turn the machine on to start the pipe rotating. Then turn the carriage handle to the right to move the reamer forward to engage the pipe. Allow the pipe to rotate at least 1/2 a turn, then remove the reamer from the pipe. That completes the reaming process. (Fig. 34)

## ⚠ CAUTION

- When processing a stainless steel pipe, use the same rotation speed for reaming as used for threading the pipe.




Fig. 33




Fig. 34

## 12. Cutting threads (Manual-open Die Head)

When using a Manual-open Die Head ( $\frac{1}{2}$  - 2"), ( $2\frac{1}{2}$  - 3") check that the die head and dies you are using are suitable for the pipe you are working on.

### **CAUTION**

Start the thread cutting process with the carriage to the right of the red line on the front support bar.

If you start cutting a thread with the red line on the carriage support bar hidden from view, the carriage could knock into the base, which could lead to damage or possible injury. (Fig. 35)  
If the machine happens to stop rotating in the middle of cutting a thread, turn the machine off immediately and pull out the plug. Failure to do so could result in fire or damage to the motor.

- To match the size of the thread, align the scale on the Eccentric link (Fig. 35-1) with the thread size on the size scale on the die head, and then tighten and fix the lever nut in position (Fig. 35).

- Turn the machine on and oil will automatically flow from the die head.




- Turn the carriage handle to the right to engage the pipe with the dies.

Cut 3 or 4 threads and threading will then be performed automatically. The unit uses a series motor whose rotation speed automatically varies according to the load. (Fig. 36)

- When the thread has been cut to the prescribed dimensions, slowly raise the eccentric handle in the direction of the arrow and release the dies to complete the threading process.

(Note: If you release the dies too abruptly, it may result in an imperfect finish such as a step-edged thread). (Fig. 37-1)

- Finally, complete the process by releasing the die head from the pipe by turning the carriage handle to the left. If you place the die head in the raised position, the flow of oil will stop. (Fig. 37-2)




### **Precautions when threading**

- Care when the dies come into contact with the pipe (Fig. 38)

Engage the cutting edge of the dies very lightly with the end of the pipe. Bringing the dies too forcefully into contact with the pipe will result in damage to the dies and shorten their working life. Once the dies engage the end of the pipe, apply light pressure to the carriage handle in a clockwise direction and then gradually increase the pressure.

As the dies cut into the pipe, it is no longer necessary to apply pressure to the carriage handle as the carriage will move on its own.



# Operation Guide (Cutting threads)

## 13. Cutting threads (Uni-auto V Die Head)

### Uni Auto V Die Head

Push the cam-plate up and set the auto-open pin in position. As the dies travel along the pipe, the end of the pipe comes into contact with the pin and pushes it out of its groove to release the dies.

#### **⚠ WARNING**

Start the thread cutting process with the carriage to the right of the red line on the front support bar.  
If you start cutting a thread with the red line on the carriage support bar hidden from view, the carriage could knock into the base, which could lead to damage or possible injury. (Fig. 35)  
If the machine happens to stop rotating in the middle of cutting a thread, turn the machine off immediately and pull out the plug.  
Failure to do so could result in fire or damage to the motor.

### Setting the thread size





Loosen the lever nut and set the index line to the desired thread size and tighten firmly.

- Fit the appropriate die head as shown in Fig.39
- Push the cam plate handle forward to set the auto-open lever then set the thread size by fitting the lever nut to the appropriate position. (Fig. 40)
- Switch the machine on and oil will start flowing automatically from the die head.
- Turn the carriage handle to the right to engage the pipe with the dies.  
Cut 3 or 4 threads and threading will then be performed automatically. (Fig. 41)

- When the prescribed length of thread has been cut, the dies will automatically be released by the auto-open lever. (Fig. 42)
- Finally, release the die head from the pipe by turning the carriage handle to the left.

#### **⚠ WARNING**

When the Uni-auto die head has finished cutting, it opens quite quickly. This may cause oil or small pieces of scrap to shoot out, which could possibly lead to injury.  
To avoid this, keep your hands and face away from the machine while it is going.



## 14. Cutting threads (Profiling Die Head)

The N100A Series comes with a Profiling die head(2½ - 4") and 1 set of dies(2½ - 4")as standard accessories. Check that the dies you use match the size of pipe you are working on.


The dies used in the N100A are suitable for threading coated steel pipes. Match the correct die head and dies to the diameter of the pipe. Similarly, make sure you use the right dies for stainless steel pipe.

### ⚠ CAUTION

Start the thread cutting process with the carriage to the right of the red line on the front support bar.


If you start cutting a thread with the red line on the carriage support bar hidden from view, the carriage could knock into the base, which could lead to damage or possible injury. (Fig. 35)

If the machine happens to stop rotating in the middle of cutting a thread, turn the machine off immediately and pull out the plug. Failure to do so could result in fire or damage to the motor.




1. Lift the die head holder over onto the carriage in the direction of the arrow in Fig. 44-1, and release from the set position.
2. Change the flow of the cutting oil by turning the oil flow selector lever in the direction of the arrow in Fig. 44-2.

\*Moving the oil flow selector switch increases the flow of oil. If the switch is moved to the middle, the flow of oil decreases.




1. Move the size setting lever on the die head in the direction of arrow 1 in Fig. 45. Then align the retaining pin with the size of the pipe to be cut. Finally, insert the retaining pin into the slot in the size setting lever.




2. Pull and turn the thread length knob on the carriage and insert the pin for the appropriate size in the pin hole.

\* Make sure the end of the thread on the size adjustment plate is fully inserted into the slot. If it is not fully inserted, thread length may be affected.




# Operation Guide (Cutting threads)


3. Set the speed change lever to the appropriate speed for the pipe size. Turn the oil flow selector lever to the left.
  - You can change the speed even when the machine is at rest.
  - If it is difficult to engage the speed change lever, you can do so by turning the hammer chuck towards you manually.




4. Turn the machine on and check that the cutting oil is flowing from the die head in the right direction. If the amount of oil is insufficient, adjust as necessary with the oil flow selector switch.



5. Turn the carriage handle to the right to engage the dies with the pipe. Once the full width of the dies has engaged the pipe, release the handle.



6. When the die head knob slips off the end of the profiling board, threading is complete. Push down on the die head knob and the dies will fully open.



7. Turn the machine off. Turn the carriage handle to the left and release the die head from the pipe. Lift up the handle and the profiling board will automatically return to its original position.

## Profiling die head


### Microfine Adjustment of Thread Thickness (Fig. 51)

Microfine adjustment of thread thickness allows pipes to be cut exactly to your own requirements. Simply turn the microfine adjustment knob to the left to decrease, and to the right to increase thread thickness.  
 \*The knob is locked by a locking bolt which should be loosened with the hexagonal key provided and the knob turned three settings to the right before adjustments are made.

**Adjustable capacity**      2½ - 4" (1.5 threads)

#### **⚠ CAUTION**


Size should always be checked with a thread gauge after adjustment.



### Adjustment of Thread Depth (Figs. 52, 53)


If, even with full adjustment, thread size is not satisfactory, remove the retaining pin and reinsert the size adjustment plates. Hold in place with the retaining pin.

1. Loosen the retaining pin with a flathead screwdriver.
2. Hold onto the size setting plate and remove the retaining pin.
3. Be careful not to let and the pin and spring under the size setting lever fly out.
4. Insert the size adjustment plate as in either Fig. 68-1 or 68-2.
5. Put the springed pin in the designated hole on the opening block and press down with the size setting lever.
6. Push the retaining pin back through the opening block, and set the size setting lever and size adjustment plate.
7. Tighten the retaining pin securely with a flathead screwdriver.



### Size Adjustment Plate

If you cannot obtain the right thread even when you fully turn the collar on the size setting pin, follow the procedure set out below.




### Adjusting the Thread Length (Figs. 54, 55)

Thread length can easily be adjusted, whatever the size. Just use a hex-key to adjust the appropriate hex-socket set screw in the thread length knob. One turn to the right will decrease thread length by approx 0.7 threads. Conversely, one turn to the left will increase thread length by the same amount.

Note: Make sure you turn the hex-socket set screw so that it engages the notch in the thread length knob.

To return the normal position, align the hex-socket set screw with the red line on the thread length knob.



# Operation Guide (Measuring threads with a gauge)

## ⚠ WARNING

Threads may be affected by the condition of the dies (blades), cutting oil etc., so be sure to use a thread gauge to check the thread. This is especially important after you have changed the die set.

### 15. Measuring threads with a gauge

#### Confirming the thread diameter

- Use a thread gauge to confirm the diameter is as it should be.

#### Confirming the number of threads

- Confirm whether the thread length is as it should be according to the number of threads as shown in Fig. 59 below.

## ⚠ CAUTION

Choose an appropriate method for checking the threads on joints and other connections, such as using sealants, washing the joint, checking the torque etc.

Thread gauge




Fig. 56

Other pipe thread gauges




Fig. 57




Fig. 58

### Counting the number of threads




Fig.59

### Unacceptable threads

- Irregular shaped threads (Fig. 60 - 1)

Recognising irregular shaped threads

- Visually inspect the thread after wiping off any oil or dirt with a rag; you will find a wave-like formation.
- Gently check the surface of the thread with your fingers, feeling for any irregularity.
- Check if bits of scrap are produced when cutting.

- The diameter of the thread is too small or too large (Fig. 60 - 2)  
Check with a thread gauge.

- Distorted threads (in the case of manual die heads) (Fig. 60 - 3)  
When cutting threads that are wider than the width of the dies, you can gradually open up the eccentric handle; but then if you leave the eccentric handle in the same position and cut a thread longer than the width of the dies, the taper will remain the same width as the die and the rest of the thread will be straight.

- Threads are too small (Fig. 60 - 4)

- The thread is chipped (Fig. 60 - 5)

- Thread with uneven thickness (Fig. 60 - 6)




Fig. 60

# Optional Accessories

## Die heads

Manual DH	For Steel pipes and Bolts	$\frac{1}{4} - \frac{3}{8} + W\frac{5}{16} - \frac{7}{8}, 1 - 2, \frac{1}{2} - 1\frac{1}{2} + W1 - 1\frac{1}{4}, \frac{1}{2} - 2, 2\frac{1}{2} - 3$
	For Bolts	UNC $\frac{5}{16} - 2, M8 - 52$
	For Conduits (Thicker, Thinner)	PF16 - 54 + C19 - 51, PF70 - 82 + C63 - 75, PF92 - 104
Self-opening Die Head		1 - 1 $\frac{1}{2}, 1 - 2$

Table 4

## Dies

For Steel Pipes	BSPT	Alloy	$\frac{1}{4} - \frac{3}{8}, \frac{1}{2} - \frac{3}{4}, 1 - 1\frac{1}{2}, 2\frac{1}{2} - 2, 1 - 2, 2\frac{1}{2} - 3, 2\frac{1}{2} - 4$
		HSS	$\frac{1}{4} - \frac{3}{8}, \frac{1}{2} - \frac{3}{4}, 1 - 1\frac{1}{2}, 2\frac{1}{2} - 2, 1 - 2, 2\frac{1}{2} - 3, 2\frac{1}{2} - 4$
	NPT	Alloy	$\frac{1}{4} - \frac{3}{8}, \frac{1}{2} - \frac{3}{4}, 1 - 1\frac{1}{2}, 2\frac{1}{2} - 2, 1 - 2, 2\frac{1}{2} - 3, 2\frac{1}{2} - 4$
		HSS	$\frac{1}{4} - \frac{3}{8}, \frac{1}{2} - \frac{3}{4}, 1 - 1\frac{1}{2}, 2\frac{1}{2} - 2, 1 - 2, 2\frac{1}{2} - 3, 2\frac{1}{2} - 4$
For Conduit		Thicker conduit	PF16 - 22, PF28 - 36, PF42 - 54, G(BSPP) $\frac{1}{2} - \frac{3}{4}, G(BSPP)1 - 2,$ PF70 - 82, PF92 - 104
		Thinner conduit	C19 - 25, C31 - 51, C63 - 75
For Bolt	BSW	Alloy	$W\frac{5}{16}, W\frac{3}{8}, W\frac{7}{16}, W\frac{1}{2}, W\frac{5}{8}, W\frac{3}{4}, W\frac{7}{8}, W1, W1\frac{1}{4}$
		HSS	
	UNC		$\frac{5}{16}, \frac{3}{8}, \frac{7}{16}, \frac{1}{2}, \frac{5}{8}, \frac{3}{4}, \frac{7}{8}, 1, 1\frac{1}{4}, 1\frac{1}{2}, 2$
	Metric	Alloy	M8, M10, M12, M14 - 16, M18 - 22, M24 - 27, M30 - 33, M36 - 39, M42 - 45, M48 - 52
HSS			

Table 5

## Parts for single layer plastic coated steel pipes

Cutter Roller	Roller Blade
---------------	--------------

Table 6



**Pipe support: Hi-support (No.170050)** \*See Pg. 10, Fig. 22

## Cutting Oil:

- Miyagawa50W-R (4L/16L): Water mains
- Miyagawa246-R (4L/18L): General plumbing
- Miyagawa100SW-R (4L/16L): For Stainless Steel pipe only

## Nipple attachments

- REX Nipple Attachments are designed to be used together with our pipe threading machine to produce nipples easily.
- Refer to Minimum Length of Nipples (Table 7) to select the appropriate size.
- Refer to the Nipple Attachment Operation Manual for how to use nipple attachments.



Size	$\frac{3}{8}$ *	$\frac{1}{2}$	$\frac{3}{4}$	1	$1\frac{1}{4}$	$1\frac{1}{2}$	2	$2\frac{1}{2}$	3	4
Weight (kg)	1.5	1.5	1.5	1.5	1.9	1.9	2.8	3.2	3.5	5.0
Minimum length of Nipples (mm)	55	45	50	55	65	65	70	80	90	100

\*BSPT only.

Table 7

# Maintenance & Care

## ⚠ WARNING

- Before inspecting or performing maintenance on the unit, always set the switch to the OFF position and remove the plug from the power outlet.  
If the unit is left plugged in, it may begin operating unexpectedly, resulting in injury.
- If you discover any problems during inspection or maintenance, look up the symptoms in the "Troubleshooting" table and take the appropriate action as noted in the table.  
Continued use of the unit without correcting the problem may result in heat, smoke or fire and lead to accident or injury.

### 1. Grease, Oil

- Greasing the main shaft bearing.  
Be sure to apply grease to the main shafts and bearings about once a the month. (Fig. 62- 1)
- Oiling the pipe cutter  
Before you operate the machine, be sure to maintain lubrication by applying spindle oil or machine oil to the thread on the cutter handle, roller shafts and blades once a day. (Fig. 62 - 2)




Fig. 62

### 2. Adjustment of the V-belt

From time to time, adjust the play on the V-belt as needed.

1. Remove the rear cover by undoing the screws.
2. Slightly loosen the 2 head-cap screws (A & B), If screw (C\*) and the nut are turned to the right, the tension pulley adjustment mount slides to the right. This pushes against the pulley, forcing the V-belt to stretch.  
Turn them to the left and the V-belt becomes looser.

#### NOTE:

If it proves difficult to loosen the pulley by pushing screw (C\*), remove the condensers (D).  
To remove the condensers, loosen the two screws (E) at either end of the bracket that fixes them to the machine.

3. Re-tighten the two head-cap screws.
4. Replace the rear cover.




Fig. 63

V-Belt No.:(JIS) A-24

### 3. Cleaning the oil tank

As tiny bits of scrap accumulate in the tank, be sure to clean it at least once a month. (Fig. 64)

- \* There should be 3 liters of cutting oil in the tank.
- \* Use REX cutting oil only.

#### Cleaning the tank

- First loosen the wing bolt, and while holding onto the wire, lift up and remove the scrap tray.
- Remove the strainer by using a Phillips screwdriver to loosen the round head screw that fastens the oil tube to the strainer.
- Remove the drain plug and drain off the cutting oil.
- Replace the drain plug once all the scrap in the tank has been removed. Put the strainer back before replacing the cutting oil.






Fig. 64

## 4. Structure and care of the chuck jaw set



As shown in Fig. 66, the insert set consists of 4 parts: the chuck jaw insert at one end of the chuck jaw, and the spring retainer, spring, and set screw at the other.

When changing the chuck jaw insert, turn the hand wheel so that the indent is directly over the chuck jaw and remove the set screw inside it.

Also, if the 6 bolts that fix the chuck in position come loose, it will affect thread cutting, so check regularly and tighten as needed.



## 5. Wiring diagram



## Servicing and Repairs

This machine is produced with great precision; therefore, should the machine fail to operate normally, do not repair it by yourself; contact your distributor or REX INDUSTRIES CO., LTD.

If parts are required or if you have any questions, please contact us at your earliest convenience.

Availability of Replacement Parts

Replacement parts are maintained for a period of 7 years after production of this model has been terminated.

Electrical parts, however, will remain available for a period of 5 years.

# Servicing and Repairs

## ⚠ WARNING

- If the problem you have and the appropriate remedy are not shown in the table below, do not attempt to disassemble or repair the unit yourself.
- If the problem and remedy are not shown in the table, or if the table indicates that you should have the unit repaired or serviced, consult your distributor or REX.
- If this product is repaired by someone who does not have the proper knowledge or technical skill to do so, the product may not operate properly, or an accident or injury may occur. In the event of a problem, always check the table before contacting REX Industries or your dealer.

## Troubleshooting

Problem		Cause	Remedy
Machine does not operate properly when turned on.	The motor is not running.	The plug is disconnected.	Insert the plug into the power socket.
		Voltage is low.	Check the voltage. (Pg. 10)
		The motor is burned out.	Repairs are needed.
		The switch is damaged.	Repairs are needed.
	The motor is running.	The gear is broken.	Repairs are needed.
Rotation of the main shaft is defective.		Voltage is too low.	Check the voltage. (Pg. 10)
		The motor is burned out.	Repairs are needed.
No oil flow.		Amount of oil is too low.	Replenish oil.
		Scrap clogging the flow.	Remove scrap in the oil tank.
		The die head is not fitted correctly.	Fit the die head in the correct position.
Oil flows out of the back of the pipe.		Rear chuck is set too low.	Raise the rear chuck.
Difficulty in attaching the die head.		Scrap is in the way.	Remove scrap attached to the die head post and hole.
		Die head is obstructed by cut-off pipe etc. on top of the tank cover.	Remove the obstruction.
Moving parts do not move smoothly.		Moving parts blocked by scrap.	Remove scrap.
Dies do not engage pipe correctly.		The dies are worn.	Replace with new ones.
		The dies are chipped.	Replace with new ones.
		The dies are not inserted in the correct position.	Match the dies to the number on the die head.
Threading cannot be performed correctly.	Too Large /Small	The die head is not adjusted correctly.	Adjust the die head according to the procedures on Pgs. 13 - 18.
	Too Long /Short	The die head is not adjusted correctly.	Adjust the die head according to the procedures on Pgs. 13 - 18.
		The dies are worn.	Replace with new ones.
		The dies are chipped.	Replace with new ones.
		Thread cutting oil has deteriorated.	Replace with new oil.
		The dies are not inserted in the correct position.	Match the dies to the number on the die head.

Table 8

# **Guarantee and Exemption from Liability**

1. Should the machine happen to break down for no apparent reason, despite normal and correct use, repairs and service parts shall be provided free of charge as outlined below.

Repairs shall be provided free of charge for a period of one year from date of purchase. Dates, procedures and methods for providing repairs and service parts shall be decided in consultation with the customer.

After the one-year guarantee period, all repairs and service parts will be charged.

Repairs may be charged even within the guarantee period under the following circumstances:

- if the machine has not been used according to the instructions in the Operation Manual
- if it has been used for anything other than its intended purpose
- if it has not been repaired according to the Operation Manual or if it has been remodeled
- if blades or consumables need replacing
- if the machine has been handled in an inappropriate way.

2. REX will accept no responsibility under the following circumstances:

- if a malfunction or accident occurs as a result of fire, abnormal fluctuations in voltage, damage from flood, earthquakes, lightning or other natural disasters, war, conflict, riot, terrorism or pollution, etc.
- when the machine has not been operated according to the Operation Manual
- when the machine has been used incorrectly, repaired or remodelled inappropriately
- when a malfunction or accident results from using a thread made on the machine, or leaving it lying around and/or exposed to the elements
- when a malfunction or accident results from using a thread produced on the machine either while or after connecting it to a joint.

3. Any costs incurred by the manufacturer shall not exceed the purchase price of the machine.

# **REX**

## **REX INDUSTRIES CO., LTD.**

Overseas Sales Dept. & Factory :

1-9-3, Hishiyahigashi, Higashi Osaka 578-0948, Japan

Tel.: +81 - (0)72 - 961 - 9820 Fax.: +81 - (0)72 - 961 - 9878

URL <https://www.rexind.co.jp>

6V850-CE2

N100A

1403D 0100