


RB TUBE CUTTER

PARTS LIST

Date of issue: August 2007



Model 30mini (NEW)



Model 22 (NEW)


Contents

1. RB Tube Cutter 22
2. RB Tube Cutter 30miniS/30miniP
3. RB Tube Cutter 30/30S/30PE
4. RB Tube Cutter 42/42S/42PE
5. RB Grooving Tool 42M
6. RB Tube Cutter 67/67S/67PE
7. RB Grooving Tool 67M

REX


RB cutter 22

2017/5/29

[illegible]

RB cutter 30mini S
RB cutter 30mini P


2016/11/17



No.	Code no.	PARTS NAME			Q' ty	REFERENCE
1	RB91	Body			1	
2	RB92	Arm			1	
3	RB03	Roller pin			2	
4	RB04	Roller collar			4	
5	RB94	Carriage thread			1	
6	RB27	Cutter wheel pin			1	
7	424242	Cutter wheel for copper, coated tube pipe (JP pkg)			1	Assembled with No.10 Bearing
	424240	Cutter wheel for stainless (Japanese pkg)			1	Assembled with No.10 Bearing
8	RB93	Grip			1	
9	RB95	Arm nut			1	
10	RB12	Bearing		695ZZ (5×13×4)	8	
11	RB98	Thrust bearing		(6×12×4.5)	1	
12	WY04	E ring		(4mm)	1	
13	WY05	E ring		(5mm)	1	
14	WL32	Socket head cap screw	Cutter wheel pin	(M3×5)	1	

RB cutter 30
RB cutter 30S
RB cutter 30PE


2016/11/17



No.	Code no.	PARTS NAME		Q' ty	REFERENCE
1	RB21	Body A	Body A & B set	1set	
2	RB22	Body B			
3	RB23	Roller pin		2	
4	RB24	Roller collar		4	
5	RB25	Ring		1	
6	RB26	Cutter wheel holder		1	
7	RB27	Cutter wheel pin		1	
8	RB28	Grip		1	
9	RB29	Carriage thread		1	
10	RB30	Grip rubber		1	
11	RB31	Side protector		2	
12	RB32	Lower protector		2	
13	RB33	Washer		2	
14	RB34	Slide stop ring		1	
15	424232	Cutter wheel for copper (Japanese pkg)		1	Assembled with No.16 Bearing
	424233	Cutter wheel for stainless (Japanese pkg)		1	Assembled with No.16 Bearing
	424284	Cutter wheel for stainless (English pkg)		1	Assembled with No.16 Bearing
	424237	Cutter wheel for lined copper pipe (JP pkg)		1	Assembled with No.16 Bearing
16	RB37	Bearing	625ZZ (5×16×5)	2	
17	RB39	Bearing	696ZZ (6×15×5)	6	
18	W552	Truss screw	(M5×8)	1	
19	W044	Socket head cap screw	(M4×15)	2	
20	WY04	E ring	(M4)	1	

RB cutter 42
RB cutter42S
RB cutter 42PE


2016/11/17



No.	Code no.	PARTS NAME		Q' ty	REFERENCE
1	RB41	Body A	Body A & B set	1set	
2	RB42	Body B			
3	RB23	Roller pin		2	
4	RB24	Roller collar		4	
5	RB25	Ring		1	
6	RB43	Cutter wheel holder		1	
7	RB27	Cutter wheel pin		1	
8	RB28	Grip		1	
9	RB44	Carriage thread		1	
10	RB30	Grip rubber		1	
11	RB31	Side protector		2	
12	RB32	Lower protector		2	
13	RB33	Washer		2	
14	RB34	Slide stop ring		1	
15	424232	Cutter wheel for copper (japanese pkg)		1	Assembled with No.16 Bearing
	424233	Cutter wheel for stainless (Japanese pkg)		1	Assembled with No.16 Bearing
	424284	Cutter wheel for stainless (English pkg)		1	Assembled with No.16 Bearing
	424237	Cutter wheel for lined copper pipe (Japanese pkg)		1	Assembled with No.16 Bearing
16	RB37	Bearing	625ZZ (5×16×5)	2	
17	RB39	Bearing	696ZZ (6×15×5)	6	
18	W552	Truss screw	(M5×8)	1	
19	W044	Socket head cap screw	(M4×15)	2	
20	WY04	E ring	(M4)	1	

RB grooving tool 42M


2016/11/17



No.	Code no.	PARTS NAME		Q' ty	REFERENCE
1	RB41	Body A	Body A & B set	1 set	
2	RB42	Body B			
3	RB23	Roller pin		2	
4	RB24	Roller collar		4	
5	RB25	Ring		1	
6	RB43	Cutter wheel holder		1	
7	RB27	Cutter wheel pin		1	
8	RB28	Grip		1	
9	RB44	Carriage thread		1	
10	RB30	Grip rubber		1	
11	RB31	Side protector		2	
12	RB32	Lower protector		2	
13	RB33	Washer		2	
14	RB34	Side stop ring		1	
15	424238	Grooving roller (Japanese pkg)		1	Assembled with no.16 Bearing
16	RB37	Bearing	625ZZ (5×16×5)	2	
17	RB39	Bearing	696ZZ (6×15×5)	6	
18	W552	Truss screw	(M5×8)	1	
19	W044	Socket head cap screw	(M4×15)	2	
20	WY04	E ring	(4mm)	1	

RB cutter67
RB cutter67S
RB cutter 67PE


2016/11/17



No.	Code no.	PARTS NAME		Q' ty	REFERENCE
1	RB61	Body		1	
2	RB62	Roller pin		4	
3	RB63	Roller collar		8	
4	RB65	Cutter wheel holder		1	
5	RB66	Cutter wheel pin		1	
6	RB67	Grip		1	
7	RB30	Grip rubber		1	
8	RB31	Side protector		2	
9	RB32	Lower protector		4	
10	WY06	E ring	(6mm)	1	
11	424234	Cutter wheel for copper (Japanese pkg)		1	Assembled with No.12 Bearing
	424235	Cutter wheel for stainless (Japanese pkg)		1	Assembled with No.12 Bearing
	424286	Cutter wheel for stainless (English pkg)		1	Assembled with No.12 Bearing
	424236	Cutter wheel for lined copper pipe (Japanese pkg)		1	Assembled with No.12 Bearing
12	RB74	Bearing	606ZZ (6×17×6)	2	
13	RB37	Bearing	625ZZ (5×16×5)	12	
14	RB69	Return spring		1	
15	RB70	Lock spring		1	
16	RB68	Half nut		1	
17	RB03	Roller pin		1	
18	WL37	Spring pin	(3×25)	2	
19	WY05	E ring	(5mm)	1	
20	RB75	Spacer		1	for PE

RB grooving tool 67M

2016/11/17



No.	Code no.	PARTS NAME		Q'ty	REFERENCE
1	RB61	Body		1	
2	RB62	Roller pin		4	
3	RB76	Outside roller		2	
4	RB63	Roller collar		4	
5	RB65	Cutter wheel holder		1	
6	RB66	Cutter wheel pin		1	
7	RB67	Grip		1	
8	RB30	Grip rubber		1	
9	RB31	Side protector		2	
10	RB32	Lower protector		4	
11	WY06	E ring	(6mm)	1	
12	424239	Grooving roller (Japanese pkg)		1	Assembled with no.13 Bearing
13	RB74	Bearing	606ZZ (6×17×6)	2	
14	RB37	Bearing	625ZZ (5×16×5)	10	
15	RB69	Cutter wheel pin		1	
16	RB70	Lock spring		1	
17	RB68	Half nut		1	
18	RB03	Roller pin		1	
19	WL37	Spring pin	(3×25)	2	
20	WY05	E ring	(5mm)	1	



REX INDUSTRIES CO., LTD.

Overseas Sales Dept. (Head Office & Factory):

1-9-3, Hishiyahigashi, Higashi Osaka 578-0948, Japan

Tel.: +81 - (0)72 - 961 - 9820 Fax.: +81 - (0)72 - 961 - 9878

URL	http://www.rexind.co.jp
-----	---

- Specifications, colour, etc. may be changed without prior notification.
- For environmental considerations, this parts list has been printed using soy ink and recycled paper.

P.L.RBTC-E3
1705R 0000